

Thank you for purchasing this LuxenHöme planter. It has been manufactured to the highest standards of safety and quality.

### Care Instructions for your Planter:

We recommend cleaning the planter before using it. New planters may often have residue from production.

Whenever you put new soil into a planter, it is best to clean the planter first.

### Cleaning tips for each type of planter material:

- **MgO (Magnesium Oxide) Planter:** Use water and a soft washcloth.
- **Ceramic Planter:** Use water and a soft washcloth.
- **Polyresin Planter:** Use water and a soft washcloth.
- **Plastic Planter:** Use water, mild soap (optional), and a soft washcloth.
- **Galvanized Steel Garden Bed Planter:** Use water, mild soap (optional), a soft brush or washcloth, and dry cloth (to dry after washing).
- **Iron Cachepot Planter:** Use water, mild soap (optional), and a soft washcloth.
- **Wood Planter:** Rinse with water. Take care when handling the wood panels, as the finish may be rough. Special note for wood planters: Treat the wood periodically with a water-based protectant. This will help extend the life of your wood garden bed.

### When reusing MgO, Ceramic, Polyresin, Plastic, Galvanized Steel, or Wood Planters:

1. Empty your planter of any dirt and dead plant material
2. Rinse the planter with a hose to remove dirt sticking to the sides
3. Wipe clean!

Depending on the planter material, the only task really needed to clean a planter or garden bed planter is water and a soft washcloth or soft brush. Let the planter dry before planting anything in it.

By cleaning your planter regularly, you will not only extend the planter's life but also allow for healthy plants to grow. You will enjoy the results for many seasons to come.

### **Use Instructions for your MgO, Polyresin, Ceramic, and Plastic Planter:**

- Place the planter on a level ground or surface.

### **Special consideration for planters crafted from magnesium oxide or polyresin material:**

- It is best if the planter is not left in standing water or snow for long periods of time. Standing water or snow may cause damage to the base of your planter.
- During extreme winter conditions, we recommend moving your planter to a sheltered, dry location to help prevent damage to your planter.

### **Use Instructions for your Galvanized Steel and Wood Garden Bed Planter:**

- Select level ground for your garden bed planters. Some garden beds have an open base. In this case, select a location ideal for plant growth).
- Assemble as instructed.
- The garden beds are recommended for outdoor use.

### **Use Instructions for your Cachepot Planter:**

If your cachepot planter set comes with a stand or legs, follow the instructions provided. Some assembly may be required.

Cachepot planters are perfect for dressing up your potted plants without re-potting or disrupting planter root growth.

You can use the cachepot planters for artificial plants as well.

Our decorative metal pots also make great accent decorations and unique storage containers for everyday home accessories.

### **Special consideration for cachepot planters made of metal:**

- These cachepot planters are approved for indoor use only.
- The metal pots are not waterproof or watertight. They are not meant for direct planting. You can place your already potted plants in these metal pots to dress up your existing planter pots.

**Tip:** Remove the potted plants before watering and allow to drain before putting them back in the metal cachepot planters.

**Special note for cachepot planters:** These are indoor use. The metal pots are not waterproof or watertight. They are not meant for direct planting. You can place your already potted plants in these metal pots to dress up your existing planter pots.