


edishinē

Floor Lamp

[Instruction Manual]




Thank you for your purchase.
Please contact us if you have any questions,
and we will get back to you within 24 hours.
Please attach your Order ID so that
we can serve you better.

CAUTION

1. Before assembly, place all parts out on a clean flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there are any defects in the wire, DO NOT continue to assemble. Please send an email to our Customer Service immediately.
3. Consult a qualified electrician if you have any electrical questions.
4. Never drape clothes over the lamp.
5. To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keep children and pets away.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and hand it over when you transfer the product.

Packing List



1



2




3



4

Part	Description	Quantity
1	Column Floor Lamp	4x2
2	Base	1x2
3	Adapter	1x2
4	Remote Control	1x2

ASSEMBLY INSTRUCTIONS



1. Screw the Column Floor Lamp (A) clockwise onto Base (B) until tight.
2. Insert the four light poles B, C, D and E into the fixed order from bottom to top.
3. Connect the Adapter connector (F) to the Adapter (G) and then Spin lock.
4. Place the floor lamp where you need it and plug into the power supply(H).

FUNCTIONS

Foot Switch


Three color temperatures(3000K/4500K/6000K)

Stepless Dimmable

Press the switch once to turn the light ON; Short press this button in turn to select the color temperature(3000K/4500K/6000K).At last, short press this button to turn off.

After the short press to turn it on, and then Long press the foot switch, the light will gradually to brighten or darken, just moves your foot away when you think the brightness is OK.

Remote Control



- 1.Shutdown button (Long press the shutdown button for 3 seconds until the blue light flashes to unpair the floor lamp and remote control. If necessary, you can re-pair with other remote to control this floor lamp)
- 2.Brightness + (7 levels)
- 3.Brightness - (7 levels)
- 4.3 color temperatures: 3000K/4500K/6000K
- 5.Power button (Please power on this lamp first, install one 12V 23A battery on the remote control and close to the lamp, and then long press the remote control power button for 3 seconds until the blue light flashes once and the code is successfully matched, then it can be used normally. Or other remote controls which are not paired with this floor lamp cannot control this lamp)
- 6.Color temperature - (7 levels)
- 7.Color temperature + (7 levels)
- 8.Night light mode (Can set CCT to 3000K, 30% brightness)

Memory function: the floor lamp can remember the mode of the brightness and color you settled before closing.

Specifications

- Product Height: 57.5 IN
- Base Length: 7.8 IN
- Wire Length: 70 IN
- Materials: Iron, PC
- Input Voltage: AC100V-240V 60Hz
- Max. Load Power: 19W
- Max. Lumens: 1100LM
- Color temperature: 3000K/4500K/6000K

One Year Limited Warranty

EDISHINE warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation. Our dedicated customer service team will get back to you within 24 hours.