

INSTALLATION FILE

BATTERY INSTALLATION SECTION



Step:1

Press the upper left corner of the wooden door to pop open the cabinet door, then take out the key

(In the yellow bag)



Step:2

Open the emergency keyhole cover

(Press the right edge of the emergency key cover to open it.)



Step:3

Insert the key and turn it to the left, while turning the handle to the right to open the cabinet door.

(Note: Both operations must be carried out simultaneously.)

Step:4



Turn the handle of the inner cabinet.



Take out the accessories: battery, emergency battery box



Step:5

Open the battery box cover above the cabinet door



Step:6

Install 4 AA batteries

(Make sure the positive and negative poles aren't installed in the wrong way.)

PASSWORD SETTINGS SECTION



Step:1

Find the code modification button



Step:2

Short press for 1 second to enter the settings mode.

Long press for 5 seconds to restore factory settings


To exit, please press the “*”

Note: * This key can be used as either the "1" key or the "2" key.




Initial manayement password:123456

- 1.Press briefly for 1 second and then release immediately
- 2.Enter the management password and press "#"



1.To modify your password, please press "1"

- 2.Enter the new password and press “#”
- 3.Enter the new password again and press "#"
- 4.Setup completed



1.To add fingerprints, please press "2"

- 2.Place your finger on the fingerprint aperture.
- 3.Press repeatedly from multiple angles for 4 to 5 times
- 4.The aperture remains constantly lit and turns green.
The fingerprint setting has been successful.

PS:Ifyou want to add a second fingerprint, please press 2 again to proceed with the addition.



1.To modify the management password, press "4"

- 2.Enter the new password and press "#"
- 3.Enter the new password again and press "#"
- 4.Password set successfully



1. Add facial recognition, please press "7"

2. The camera hole emits red light.

3. Located two feet away from the camera hole

4. 360-degree rotation of the head

PS: Only safes with this function can be set up.



1. The selected position will turn off the lights, and the input operation has been successfully completed.

2. To exit, please press the "*" key.



1. Method for unlocking and entering by reading palm patterns

2. Wake-up panel input: "33"

3. Press the red button for one second and then release it.

4. Point your palm towards the camera

PS: Only safes with this function can be set up.



1. The selected position will turn off the lights, and the input operation has been successfully completed.

2. Adding successfully means the entry is successful.

USE THE SET UNLOCKING METHOD TO UNLOCK



Step:1

PASSWORD UNLOCK

ENTER THE SET

PASSWORD AND PRESS "#"



Step:2

FINGERPRINT

RECOGNITION FOR

UNLOCKING



Step:3

FACIAL RECOGNITION

UNLOCKING

PS:Only safes with this
function can be set up.



Step:4

UNLOCK USING PALM

RIDGES

PS:Only safes with this
function can be set up.