

CONTROL PANEL

SAFETY

DIAGRAMS

INSTALLATION

FILTERS

CARE

TROUBLESHOOTING

PURCHASE INFO



Light: Turns on or off under hood LED lights.

Fan 1: Adjusts fan to the lowest speed.

Fan 2: Adjusts fan to the second level speed.

Display: Displays icon for power, light fan and time. Time can be set by the follow method:
Hold power button for 3 seconds until the hour display flashes.
Press "Fan 1" to increase hour.
Press "Fan 2" to decrease hour.
While hour is still flashing, touch the power button to move to minutes setting
Press "Fan 1" to increase minutes.
Press "Fan 2" to decrease minutes.
While minutes are still flashing touch the power button to finish setting clock.

Fan 3: Adjusts fan to the third level speed.

Fan 4: Adjusts fan to the fourth or highest level speed.

Power: Turns unit on or off and adjusts time setting.