





Assembly Instructions


CAUTION : You must read these Assembly Instruction before you proceed

Care & Maintenance

-  ● Not for commercial use. For residential use only.
-  ● Do not put hot items directly on furniture surface.
-  ● Do not clean furniture with harsh cleansers or polish.
-  ● To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.
-  ● Children should not climb or jump on the furniture.
-  ● Do not write on furniture without a padded barrier to protect the surface.
-  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-  ● Stains may be removed with mild soap solution and damp cloth.
-  ● Keep away from sources of ignition.
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look into the Seat Panel for hardware packs.

DOUBLE LOUNGE CHAISE







CAUTION: This **Double Lounge Chaise** is NOT a TOY



Keep your child / children at bay during the assembly process.

For turning the **Double Lounge Chaise** and to prevent damage to the **Double Lounge Chaise**, 02 adults may be needed to execute this action







Parts List

Label	Picture	Description	Qty
A		L-Back Leg	1
B		R-Back Leg	1
C		L-Front Leg	1
D		R-Front Leg	1
E		L-Main Frame	1

Parts List

Label	Picture	Description	Qty
F		R-Main Frame	1
G		Support Leg	2
H		Cushion	2


Hardware:

No.	Picture	Description	Q.ty
①		Screw (M6x90)	13
②		Screw (M6x60)	3
③		Bolt (M6x70)	3
④		Bolt (M6x40)	3
⑤		Wood Cap	13
⑥		Allen Wrench	2


Assembly Preparation:

Before Begining Assembly:


- ①




x13
- ②



x3
- ③




x3
- ④




x3
- ⑤




x13
- ⑥



x2



● Read instructions, cover to cover



● Have 2 adults on hand for assembly



● Do not assemble on the flooring or carpet




● Assemble on a clean, non-marring surface (packing foam)




● Save all packaging until finished.

Assembly Steps:




This **Double Lounge Chaise** has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the **Lounge Chaise** parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise the parts and steps before assembly.

Step 1:




Unpack and place all the parts on a clean, non-marring surface.

Step 2:




Insert L-Back Leg (A) and L-Front Leg (C) to L-Main Frame (E). Then:
Step 2.1: Fix L-Back Leg (A) to L-Main Frame (E) by 3pcs Screw (1) and Allen Wrench (6).
Step 2.2: Fix L-Front Leg (C) to L-Main Frame (E) by 3 pcs Screw (1) and Allen Wrench (6).
DO NOT fully tighten the Screws.

Step 3:




Insert L-Back Leg (A) and L-Front Leg (C) to L-Main Frame (E). Then:
Step 3.1: Fix R-Back Leg (B) to R-Main Frame (F) by 3pcs Screw (1) and Allen Wrench (6).
Step 3.2: Fix R-Front Leg (D) to R-Main Frame (F) by 3 pcs Screw (1) and Allen Wrench (6).
DO NOT fully tighten the Screws.

Step 4:




Fix **Assembled parts in Step 2** to **Assembled parts in Step 3** by using 2pcs Bolts (③) and Allen Wrench (⑥).
DO NOT Fully tighten the Bolts.

Step 5:




With the help of your adult partner, Turn over **Double Lounge Chaise** then fix L-Main Frame (E) to R-Main Frame (F) using 2pcs Bolts (④) and Allen Wrench (⑥).
DO NOT Fully tighten the Bolts.

Step 6:




Fix Support 2pcs Leg (G) to the **Assembled parts in Step 5** by using 2pcs Bolts (②) and Allen Wrench (⑥).
DO NOT Fully tighten the Bolts.

Step 7:




Place 2pcs Cushion (H) on the Double Lounge Chaise.

Step 8:



With the help of your adult partner, Turn over Lounge Chaise. Then affix 12pcs Magic Tape Straps as shown above.

Step 9:



Inspect it and make sure all parts are adequately connected.
Gently and gracefully, sit onto the all **Double Lounge Chaise**. This will help to align all the parts at all joint areas.
Then get off the Lounge Chaise and in a sequential manner, gradually tighten all Screws at all joints until evenly connected.
If there are still wobbles, loosen the Screws and execute this same process.
Using Wood Cap to cover Screw Head
WARNING!! IF LOUNGE CHAISE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.
Your Double Lounge Chaise is ready for use.
This Double Lounge Chaise can only be used on a flat, level surface.