

Assembly Instructions

Hickory Dining Chair with Arms



Thank you for choosing our product.

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture,
or if you have missing hardware, please email us.

PARTS (included)

(A) Chair (1)

(B) Left Arm (1)

(C) Right Arm (1)



HARDWARE (included)

(a) 1 $\frac{3}{4}$ " Bolts (4)

(b) Allen Wrench (1)



TOOLS NEEDED

None

STEP 1

Fasten the arms to the chair as shown (photo 1) aligning the holes in the arms and arm braces with the ones in the chair seat and back. Insert a 1 $\frac{3}{4}$ " bolt into each hole. (See photo 2.) Tighten with the Allen wrench.




photo 1




photo 2