



Component List




A X1




B X1




C X1



D X1




E X1



F X1

Hardware




1 X4

M8x20mm Bolts




2 X4

Ø 8 mm washers




3 X1

M6x55mm Bolt




4 X1

M6 Nut



5 X1

M6x12mm Bolt



6 X1

M6x39mm Nut




7 X1

Securing Knob



8 X1

Allen key



9 X1

Wrench

Important Safety & Warnings

To make the umbrella more stable, you can use ground stakes (requires 8 self-provided M8x20)

- Base weights are not included. Do not use the umbrella without adding compatible weights / anchors.
- Do not use in snow, heavy rain, thunderstorms, or strong / gusty winds.
- Always close and strap the canopy when not in use.
- During initial assembly, start all screws loosely; tighten fully only after all parts are aligned.
- Do not use this product in any manner inconsistent with the manufacturer's instructions.



Use & Care


- Placement — Place on a stable, level surface; check all bolts / knobs are secure before each use.
- Weather — Close and secure the canopy in rain, strong / gusty winds, snow, or thunderstorms.
- Storage — Close and strap the canopy when not in use; store in a dry, weather-protected area or use a protective cover.
- Periodic check — Check and re-tighten all bolts, screws, and knobs every 90 days.

Cleaning



- Wipe with a soft cloth dampened with warm water and mild detergent.
- Do not use abrasive cleaners or solvents.


Step 1

3 1pc	4 1pc	5 1pc	6 1pc	8 1pc
				
M6 × 55mm bolt	M6 Nut	M6 × 12mm bolt	M6 × 39mm Nut	Allen key




Step 2


1 4pcs	2 4pcs	7 1pc	9 1pc
			
M8 × 20mm bolt	Ø 8 mm washers	Securing Knob	Wrench




Step 3




Step 4




Step 5



Step 6



Step 7



Step 8

