

INSTRUCTIONS FOR YOUR PRODUCT



Step 1

Connect the flexible hose to the pump.



Step 2

Fill the reservoir with water and take a note of the level that the water reaches for future reference when topping off.



Step 3

Plug in and switch on, after short while the water will start to flow.

Adjust the pump flow rate to achieve the desired effect and to minimize any splashing. Splashing can occur if the flow rate is too high or the feature is too full. The flow rate can be increased or decreased by moving the flow rate control slider on the pump body. Moving the switch towards (+) will increase the flow rate and moving it towards (-) will decrease it.

WARNING:

Never turn on the pump before the fountain is full of water. Also do not let the water level fall below the top of the pump as the pump will become damaged if run without water. Fountain should be placed on a level surface.