# ASSEMBLY INSTRUCTIONS



## + Do Not Use Power Tools

## + Suggested Adults

NOTE:

**1** Read instructions cover to cover.

**2** Save all packaging until assembly is completed.

## 1 IMPORTANT SAFETY INFORMATION

**Do not** assemble the product if any of the following parts arrived damaged:

part # - Corner base
part # - Corner cushion
part # - Armless chair base
part # - Armless chair cushion
part # - Chrome leg
part # - Gold leg

**Do not** assemble if any of the following Hardware parts are missing:

part # - Allen wrench
part # - Bolt M8"*35mm
part # - Washer M8*16mm
part # - Connect metal plate

## 2 IMPORTANT ASSEMBLY INFORMATION

**Assembly Step** If loosening persists,please make sure to tighten all the bolts periodically,or use a thread locker adhesive.

## + Parts Included

① Corner base
1pc



② Corner cushion
1pc

③ Armless chair base
1pc



④ Armless chair cushion
1pc



⑤ Chrome leg
8 pcs

⑥ Gold leg
8 pcs

## + Hardware Included

**A** Allen wrench
1 pc

**B** Bolt M8"*35mm
24pcs

**C** Washer M8*16mm
24 pcs

**D** Connect metal plate
100*75*18mm
2 pcs



# ASSEMBLY INSTRUCTIONS

1




2 Remove the cushion from each product.



3 Assemble connect metal plate,then put cushions back on the seat.