



ASSEMBLY INSTRUCTION

HFSN-902


Ax1



Bx1



Cx1



Dx1




Ex4




Fx1




①



②



③



④

