


Instruction Manual

Please save this manual for future reference.

Product Name:	See, Hear, Speak No Evil Set of 3 Garden Easter Island Solar Statues

Thank you for purchasing this LuxenHome product. This product has been manufactured with the highest standards of safety and quality.

Parts included: 3 x Easter Island Tiki Statues, 3 x Solar Panels, 3 x Pole and Stake



Instruction Manual


Please save this manual for future reference.

Product Name:	See, Hear, Speak No Evil Set of 3 Garden Easter Island Solar Statues

Instructions:

- Select a flat surface for your statues with solar lights.
- Assemble the solar light panel to the pole and ground stake.
- To turn on, press the On/Off push button.
- For best results, allow to charge in direct sunlight for a minimum of 8 hours.
- After fully charged, it will automatically light at night when the solar panel is set to "On".
- To extend battery life, turn to the off position when not in use for long periods of time.
- Battery: 1pc AA Ni-MH 1.2V 300MAH (included)

To change the battery:



- Turn off the solar light.
- Remove the four small screws on the back of the solar panel.
- Replace the old battery with a new battery that is the same type (1 x AA Ni-MH 1.2V 300MAH).
- Reattach the back of the solar panel by screwing in the small screws.

Trouble Shooting Tips:

If your solar light does not turn on at night, it may be caused by the following:

1. Check to see if the solar panel On/Off is in the "OFF" position.
Resolution: Push the button to the "ON" position and allow the solar light to be charged for at least 8 hours in direct sunlight.
2. Battery may not be fully charged.
Resolution: Make sure the solar light is placed in an area where the solar panel receives the maximum amount of full direct sunlight every day.
3. The solar light may be located too close to other light sources (such as porch light or street lantern).
Resolution: Relocate away from external light source.
4. The rechargeable battery may need to be replaced.
Resolution: Replace with batteries of identical specification.



WARNING:

Do not dispose of batteries in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling batteries.