



Rinse with water



When it rains, place it vertically



Dry in the air

Cleaning

1. Please take out the fiberfill before cleaning the removable polyester cover of the cushion and rinse the fabric cover separately. For non-removable polyester cover, please put the whole cushion vertically and rinse it with clean water.
2. To avoid the deformation of cushions, please do not wring it. Just place it vertically in air-seasoning place for airing dry after rinse thoroughly.
3. Spot cleanable with mild soap and lukewarm water. Mild detergent is suggested when stubborn stain encountered.
4. Hand-wash in normal temperature is recommended.

Maintenance

1. Please place the cushions vertically to better let water out in raining days. We recommend you to store the cushions indoors in continuous raining days or cover when not in use for long time to extend the life of usage.
2. For reversible cushions, please turn it over once a week to allow force to distribute evenly.
3. Always slap the cushion to loosen the internal fiber and maintain its elasticity.
4. If you find the thread gets loose, do not tear it by hands, cut it level with scissor.