


Owner Manual



INSTALLATION GUIDE

ONE PERSON ASSEMBLY: 30 MINUTES (APPROXIMATE)

TOOLS REQUIRED: ALLEN WRENCH (PROVIDED)

BEFORE ASSEMBLY

- 1.Remove all packaging materials, staples and packing straps from the carton.
- 2.Confirm with Parts Checklist in Page 3.

ATTENTION

- 1.Leave sufficient space for assembly.
- 2.Do not assemble on the ground that may hurt the product.
- 3.Do not over-tighten any fittings as it may cause damage.
- 4.DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
- 5.Do not sit or stand on it before the assembly is complete.

DAILY MAINTENANCE

- 1.Recommended for indoor use only.
- 2.Wipe with a soft, dry cloth. Keep away from abrasives and household cleaners.
- 3.Check all the fittings periodically and re-tighten if necessary. Do not use the product if any part is damaged or broken.

Warranty & Return Policy

Office desk chairs are warranted from the date of purchase due to material and workmanship factors. Details as follows:

- 1 YEAR on all unmovable metal parts;
- 1 YEAR on upholstered PU leather and foam;
- 1 YEAR on component parts including control mechanism, gas cylinder, wood, plastic parts, base and casters.

To make a warranty claim, please contact us with model number purchase proof, problem descriptions as well as pictures or videos that shows the problem clearly.

Problem verified, We will:

- a) Send replacement parts.
- b) Send a new product if necessary, customer need to return the original item to our warehouse.

RETURN POLICY


30 days return policy after receiving is provided. We offer prepaid return labels for product quality issues.

Note: Original Box has to be kept for the return until you decide to keep the item.


PARTS CHECKLIST




Ax5




Bx5+1




Cx1




Dx1




Ex1



Fx1




Gx1




Hx2



Ix10(M6x16mm)




Jx4 (M8x20mm)




Kx6 (M6x25mm)




Lx4 (M8x35mm)



Mx1




Nx1




Ox1




Px1




Step 1: Insert Base Legs [**B**] one by one to the Base Center. Next, screw ten Screw [**I**] into the holes with the Allen Wrench [**P**] to attach the base and the legs.




Step 2: Insert the Casters [**A**] into the five star base. This may take significant force. Gentle squeeze the base cover and place around the center of the 5 star base. Insert the Gas Lift Cylinder [**C**] into the center of the base.




Step 3: Assemble Chair Back [E] with Seat [F] via the Iron Sheet [G] and Screws [Jx4 & Kx4]. Tighten the screws and finish with Allen Wrench [P].



Step 4: Connect the foot bracket pad to the footrest via the screw [Kx2].




Step 5: Assemble the Armrests [H] with the Chair Back [E] and seat [F] via Screws [Lx4].
 Attach the assembled seat to the assembled base by aligning the hole in the tilt mechanism to the top of the gas cylinder.
 Place the Lumbar Pillow [O] at the lumbar region of the chair.
 Connect the Massager [M] and Power Plug [N] to the same color cable.



Step 6: Enjoy your Office Chair!

BUTTON FUNCTION DESCRIPTION



1. ⓘ **Power button:** Press the device to run, Press the device again to stop.

When the device is running, by default, knead open, the red indicator lights up, the forward and reverse green indicator light is turned on randomly.

Default kneading and massage for 15 minutes

2. KNEAD button: Knead “ON/OFF” button

Press once with the red indicator on and knead; press again and close kneading.

3. MODE button: Knead the mode selection button: Selection between modes M1 and M2.

In the case of the KNEAD being turned on, the M1 mode is turned on by default, the red indicator lights up, switchable selection M2 mode.

4. HEAT button: Heating function “ON/OFF” button

Press once, heating start, red indicator light on; Press again, heat off, the red indicator is off.