




ITEM NO. DTGG1807

Scan for manual,
video & advice.



If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :


This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
100 LBS



Installation:
20 minutes.



Two Person



Before You Start

Please follow the steps below:



Unbox the package and check if all parts and accessories are complete.



If you find something missing, stop assembly and contact your supplier immediately.



Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.



NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty



We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



Are you having difficulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**




For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all 2 boxes(box A/B), then begin the assembly!




Parts List (Carton A)

A ×1



Top Panel


B ×1



Bottom Pannel

Parts List (Carton B)


C ×2



Leg


Hardware List (Carton B)

1 ×16+2




Bolt
Ø5/16" x 45mm

2 ×16+2



Spring washer
Ø5/16" x 14mm

3 ×16+2



Flat washer
Ø5/16" x 19mm

4 ×1




Allen key
M4x58mm

Assembly Instructions

Step 01

To ensure the product remains undamaged during transit, the **Top Panel (A)** and **Bottom Panel (B)** have been pre-attached using four bolts. These parts must be separated before you can begin the full assembly process. Place the **Top Panel (A)** and the **Bottom Panel (B)** upside down on a soft fabric or a clean, non-abrasive surface to prevent any scratches or damage to the finish. Using the provided **Allen Key(4)**, unscrew and remove the four bolts currently connecting the **Bottom Panel (B)** to the **Top Panel (A)**. Carefully set these 4 bolts (along with their washers) aside. Do not discard them, as they will be required later for the installation in Step 3.


4	 x1	Allen key M4x39mm
---	--	----------------------



Step 02

Place the two **Legs (C)** upright on a level surface. Align the mounting holes of the **Bottom Panel (B)** with the threaded inserts on top of the legs. Secure the panel using **Bolts (1)**, **Spring Washer (2)** and **Flat Washer (3)**. Use the **Allen Key (4)** to tighten all bolts.


1		x8	Bolt Ø5/16" x 45mm
2		x8	Spring washer Ø5/16" x 14mm
3		x8	Flat washer Ø5/16" x 19mm
4		x1	Allen key M4x39mm



Step 03

Place the **Top Panel (A)** upside down on a soft, non-abrasive surface. Position the pre-assembled leg structure onto the underside of the **Top Panel (A)**, aligning all pre-drilled holes. Use the 4 bolts and washers removed in Step 1 along with 8 new **Bolts (1)**, **Spring Washers (2)**, and **Flat Washers (3)**. Use the **Allen Key (4)** to tighten all bolts firmly.

1	 x8	Bolt Ø5/16" x 45mm
2	 x8	Spring washer Ø5/16" x 14mm
3	 x8	Flat washer Ø5/16" x 19mm
4	 x1	Allen key M4x39mm



WWW.HULALAHOME.COM

Email: customerservice@hulalahome.com

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)