








1



 1 x 2	 2 x 1	 or 3 x 1	 4 x 1	 5 x 1	 6 x 10
 7 x 2	 8 x 2	 9 M8 x 4	 10 x 2	 11 M6x40 x 8	 12 M6x10 x 12
 13 4,8x16 x 14	 14 5x16 x 2	 15 4x16 x 2	 16 x 1	 max. 80 kg Zuladung max. 80 kg additional load max. 80 kg charge limite	

2




11

M6x40 x8



x2

3



9

9

4x

12

M6x10 x4




12

8

x2

4



10 x2

12




M6x10 x8




5

13




4,8x16 x14



6


14



5x16 x2



2




B

14



16

A



2



16



7



oder/or/ou



Wichtig! Der Tisch muss vor der ersten Benutzung resettet werden.
Beachten Sie die Gebrauchsanweisung vom Bedienpanel.

Important! The table must be reset before the first use.
Follow the instructions for using the control panel.

Important! La table doit être réinitialisée avant la première utilisation.
Observez les instructions d'utilisation du panneau de commande.