

FLOOR LAMP

PACKAGE CONTENTS

A	Lamp base	x 1
B	Pole	x 4
C	Switch box	x 1
D	Lampholder	x 5
E	Lamp shade	x 5
F	Socket nut	x 5

BEFORE YOU BEGIN

1. Inspect lamp before beginning assembly. All wire connections have been made at the factory and the lamp is ready for assembly.
2. To prevent bad connections, avoid pulling wire connections when removing contents from package or during installation.
3. Be sure to tighten all parts securely.

ASSEMBLY

1. Screw the pole (B) onto the lamp base (A).
2. Screw together the remaining poles (B).
3. Screw switch box (C) onto top pole (B). Pull any excess cord gently through the poles to fit these parts.
4. Place the lamp shade (E) onto the lampholder (D) and secure with socket nut (F)
5. Install the light bulbs (not included). Only use bulbs of the specified type and maximum rated wattage or less. This lamp uses 25 Watt candelabra base bulbs.



**Use 25 watt type candelabra base bulb.
(not included)**

IMPORTANT

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRICAL SHOCK AND FIRE, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THIS SAFETY FEATURE.

