


ASSEMBLY INSTRUCTIONS

TV STAND



THIS FURNITURE MUST BE FIXED TO THE WALL

To ensure the safety of those using this closet, it is crucial to properly secure it to the wall using a wall anchor . This product includes the necessary items for fixing the furniture to the wall. However, it is important to note that incorrect installation or failure to use the tip-over device can result in serious injury or even death.


For this reason, we highly recommend that a professional installer handle the installation of the closet to the wall.

Index


What will you need?	2
Where should you start?	3
What's in the hardware bag?	4
How do the dowels and Minifix system work? (We also explain what they are)	5
Let's start assembling!	6
How much weight does your closet resist?	20
Our last recommendations for taking care of your closet	21

What will you need?


Phillips head screwdriver



Flat head screwdriver



Hammer




A flat, smooth surface. You can use the cardboard of the box or a rug.



An electric screwdriver isn't necessary, but it can make the work much easier :)

Hi! my name is Armando, and I'll be with you while you assemble this closet.




Where should you start?

This is so IMPORTANT!

Over the next few pages is the panel and hardware content for this closet.

Please make sure that the quantity of each one is correct, and that everything is in good shape.



(When the cabinet is already assembled there's no warranty for this)




Panel quantity

A - x1	B - x1	C - x1	D - x1
E - x1	F - x1	G - x1	H - x2
I - x1	J - x1	K - x2	L - x1

What's in the hardware bag?

 Wood dowel x18	 Spreading bolt x28	 Minifix cam x28	 Cover caps x20
 Panel pin x30	 Inset overlay Hinge + screw x4	 Rectangular Staple x4	 Wodeen leg x5
 Flat Head Screw x20	 Pneumatic arm + screw's x2		




Be careful!, try not to lose anything from this bag, its content is necessary for assembling your closet.

How do the dowels and Minifix system work?


this is so important too!

Everytime you're using one of these connectors during the assembly, you should follow these same steps.




Wood dowels

They are little wooden cylinders.




Put in the dowel inside the indicated hole and softly hit it until it's fully inside.




When joining two panels together, don't forget to gently hit the panels to adjust the joint.

Minifix system


It's a joint compound of two parts: a spreading bolt and a Minifix cam.




This is a Minifix cam. It has a little arrow on its upper surface.



You should insert these cams with the little arrow pointing towards the drilling on the panel's edge (shown on the left).




This is a spreading bolt. You should put it with the black plastic part facing down.




After joining two panels together you should turn the cams 180° with a phillips head screwdriver to adjust and secure the joint.

Let's start assembling!


1




2




3




4




5




6




7




8




9




10




11




12




13



14







Inserta el brazo en
el pivote

Ensabl las tapas para
asegurar el brazo


Hynge adjustment



How much weight does my tv stand resist?



*weight in pounds



Congratulations!
It's done

But don't go yet!

There are some
recommendations left for you
to take care of your table
correctly from now on.


SUPER IMPORTANT!

We suggest fixing the closet to the
wall, so we can avoid the table tipping
and harming anyone.
Be specially careful with the kids.

Taking care of your tv stand

- Do not paint the tv stand
- The table it's exclusively for indoor spaces. Do not expose it to the direct sun.
- Clean the metallic hardware with a dry tv stand.
- DO NOT overload the tv stand (see suggested loads)
- Do not hit or hammer the tv stand (only when indicated here).
- Clean it with thinner, a soft soap solution or simply a damp cloth.
- Don't drag the tv stand, lift it up with other people.
- Avoid direct contact with water, fire or exposing it to high heat.

Tv stand panels



WARRANTY POLICY

Furniture has a 1 year warranty coverage in wooden parts and hardware pieces since its manufacturing date, which you can see in the lot number printed on the product box and the assembly instructions leaflet.

Warranty covers materials and workmanship imperfections which impair the assembly or correct functioning of the closet.

This warranty is not valid if the defects or imperfections are caused by the incorrect following of the assembly instructions, warnings and recommendations, misuse, intentional damage, fire or flood, or after modifications or any kind of alteration, or repaired by someone not authorized, when it's been assembled 3 months after the date of purchase. These defects **MUST** be reported before the warranty coverage period ends. Once the product has been assembled, the company will not be responsible for defective and/or damaged parts.

This warranty is **ONLY** valid for the **ORIGINAL PURCHASER**, it doesn't apply if the product has been resold, rented, etc.

Furniture will take no liability for incidental or consequential damages caused to or by the product (This may not apply in your state).

To make this warranty valid you must write to our customer service email describing the product defect, lot number and submitting your sales receipt or proof of purchase, or contact us at our customer service line. Replaced parts will be under the product's original warranty coverage period. Damaged parts will become property of the company.

There are no other warranties applicable to this product.