

# Installation Guide

Extendable Tension Rods

## What's Included

1 Extendable Tension Rod

Rubber End Tips (attached)

**NO SCREWS - NO GLUE - NO DRILLING REQUIRED!**

**IMPORTANT:** This rod works by creating tension pressure between two solid surfaces. Ensure your mounting surfaces can handle this pressure without damage.

## TENSION ROD INSTALLATION

### 1 Prepare Your Space

Clean both mounting surfaces where the rod ends will contact. Ensure the space is clear and ready for installation.

### 2 Adjust Rod to Correct Length

Twist the rod to extend it to approximately 1/4 inch less than your measured space width. This allows room for creating tension.

**TIP:** Start slightly shorter than your space - you'll extend it further during installation to create the tension.

### 3 Position the Rod

Place one rubber tip against one mounting surface, then position the other end against the opposite surface at your desired height.

#### 4 Create Tension

While holding the rod in position, twist to extend it further until it creates firm pressure against both mounting surfaces. The rod should feel secure and not slip.

**CAUTION:** Don't over-tighten. Apply just enough tension to hold securely without damaging surfaces.

#### 5 Test Installation

Gently try to move the rod up, down, and side to side. It should remain firmly in place without slipping or falling.

#### 6 Hang Your Curtains

Thread your curtains onto the rod or use curtain rings/clips as needed. The rod is designed for lightweight curtains, voiles, and sheers.

### TROUBLESHOOTING

#### ! Rod Keeps Falling

**Solution:** Increase tension by twisting to extend the rod further. Ensure mounting surfaces are solid and not slippery.

#### ! Rod Won't Stay Extended

**Solution:** Check that the telescoping mechanism isn't stuck. Clean and ensure smooth operation before installation.

#### ! Rubber Tips Slipping

**Solution:** Clean mounting surfaces to remove dust or grease. Ensure surfaces are flat and suitable for tension mounting.

## REMOVAL & ADJUSTMENT

### 1 To Remove

Twist the rod counterclockwise to reduce length and release tension. Once loose, carefully remove from mounting surfaces.

### 2 To Adjust Height

Remove the rod completely, then reinstall at your desired new height following the installation steps.

**VERSATILE USES:** Perfect for windows, closets, doorways, laundry areas, under sinks, and any space needing temporary or permanent curtain solutions.

**WEIGHT LIMIT:** Designed for lightweight curtains, voiles, and sheers. Not suitable for heavy drapes or excessive weight.