



ASSEMBLY INSTRUCTION

Side table




Notes: Don't tighten screws completely at first, just in case parts were assembled wrong and need disassemble. Tighten screws at last when all parts are put together


1 	2 	3 3PCS	4 					
5 2PCS	6 2PCS	7 	8 	9 2PCS				
10 2PCS	11 2PCS							
A 8PCS	B M5X50 32PCS	F M6X30 6PCS	G M6X35 6PCS	N M6X10 7PCS	Y M8 4PCS	Z 7PCS	X M3.5X50 3PCS	




Y
M8
4PCS




G
M6X35
4PCS




B
M5X50
4PCS




F
M6X30
2PCS
G
M6X35
2PCS




F
M6X30
4PCS




B
M5X50
4PCS





B
M5X50
4PCS





B
M5X50
4PCS





B 
M5X50
8PCS






B 
M5X50
8PCS






A 
8PCS





A 
8PCS



X 
M3. 5X50
3PCS



Z 
M6X30
7PCS

N 
M6X10
7PCS