




Product Manual













X3

Eccentric installation principle





A  x90	B (φ12)  x90	C  x1(SET)	D  x4(SET)	E(φ3.5x12)  x70
F (φ3x30)  x18	G  x3	H (3.5x16)  x7	I  x20	J  x20
K  x1	L  x4	M  x14	N (φ3.5x14)  x5	 x5



1




2







3





4




Rotate 180°




5




6




7




8




9




10




11




12




13




14




15




16




17




18




19




20




21







22




23





24



25



26



27

