

FIREPLACE USAGE INSTRUCTIONS



1.Plug in the fireplace
2.press the ① power switch button.



3.Then press the High Temperature ② button.
Wait a moment and warm air will come out.



(③ is for lowering the temperature)



(④ for adjusting flame display size)

Tap the button, let the flame reach your preferred size, then tap again to lock it.