

ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0 : 10/09/2019
REVISION 1 : 03/09/2023
REVISION 2 : 20/11/2023
REVISION 3 : 24/01/2024
REVISION 4 : 04/03/2026

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION


AV BACKREST

1PC




BV SEAT

1PC



CV BASE

1PC



HARDWARE IDENTIFICATION

1 LONG BOLT
(Ø1/4" x 20mm - SR)

4PCS



2 SHORT BOLT
(Ø1/4" x 15mm - SR)

4PCS



3 FLAT WASHER
(Ø1/4" x 16mm - SR)

8PCS



4 LOCK WASHER
(Ø1/4" x 12mm - SR)

8PCS




5 ALLEN WRENCH
(M4 - 59mm - SR)

1PC




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3 COMPLETE





Note: Dimension tolerance $\pm 5\%$