ASSEMBLY INSTRUCTIONS

ASSEMBLY REQUIREMENTS

2-Person Assembly Assembly Time (Approximate)

30 MINUTES

Tool Required (Not Provided)

Mallet


Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damaged parts or hardware. Replacement parts are normally shipped within 2 or 3 days.

PRODUCTS PURCHASED THROUGH OUR AUTHORIZED VENDORS ONLY ARE ELIGIBLE FOR REPLACEMENT PARTS

We appreciate your business!

THIS PRODUCT IS FOR INDOOR AND HOUSEHOLD USE ONLY - NOT FOR COMMERCIAL USE.



ASSEMBLY PREPARATION

- 1. Remove all packaging materials, staples and packing straps from the carton.
- 2. Refer to Part List and Hardware List and ensure they are complete before you start assembling. Contact customer service for missing part.
- 3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION

- 1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
- 2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY

- 1. Allow ample room for assembly and in close proximity to where product will be placed.
- 2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
- 3. Please check all of the parts and quantities are included before assembly. Contact customer service for missing parts.
- 4. Identify all of the parts, hardware and quantities required for each step.
- 5. During assembly, do not over-tighten any fittings as this may cause damage.
- 6. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
- 7. Always place the product on a flat surface.
- 8. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE

- Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
- Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.
- Solid wood is impacted by heat and humidity fluctuations which may cause small joint separations or hairline cracks; place the furniture away from direct sunlight and air conditioning vents, heating vents or units to protect the furniture.

ASSEMBLY INSTRUCTIONS

PARTS LIST

NO.	COMPONENT	QTY.	
P1	TABLE TOP	1 PC.	
P2	PEDESTAL LEG WITH MOUNTING PANEL	1 PC.	


HARDWARE LIST

NO.	DESCRIPTION		QTY.	EXTRA
H1	JCBC BOLT M6 x 35MM	0	4 PCS.	1 PC.
H2	SPRING WASHER 1/4"	0	4 PCS.	1 PC.
H3	WOOD DOWEL M8 x 30MM		4 PCS.	1 PC.
H4	ADJUSTALE LEG STUD	-()	8 PCS.	1 PC.
H5	ALLEN KEY M4 x 110MM	L	1 PC.	84

*EXTRA HARDWARE FOR SPARE USE

STEP 1

- a) Lay Table-Top (P1) bottom-side up on a material that does scratch or damage the surface of (P1).
- b) Insert Wood Dowel (H3) into the 4 inter holes on Table Top (P1). Use a mallet to lightly tap in (H3) if needed.



STEP 2

- a) Attach Pedestal Leg with Mounting Panel (P2) to Table-Top (P1) via wood dowels on (P1).
- b) Use Screw (H1) fitted with Spring Washer (H2) to fasten (P2) to (P1).
- c) Use Allen Key (H5) to drive (H1). Do not tighten (H1) completely until all 4 screws are in place.
- Screw in Adjustable Leg Stud (H4) to the bottom of Pedestal Leg (P2).

With the assistance of another person, set the table right-side up. The assemble of the table is complete.

