

BBQ Grill Gazebo

8 ft x 5 ft with Hard Top

INSTRUCTION MANUAL



WARRANTY

Please read and save these instructions before attempting to set up this gazebo.

1 year limited warranty

We warrants for a period of 1 year from the original date of purchase, this product against any defects in materials or workmanship. At its discretion, we may provide replacement parts to original purchaser. Original receipt or proof of purchase as well as proof of defect is required. We will not be responsible for shipping costs incurred outside the continental USA. Warranty is valid for the original purchaser for 1 year from the date of purchase and is not transferable. This warranty does not cover any product purchased through non authorized dealers and/or on-line auction websites.

This Warranty Does Not Cover

This 1 Year Limited Warranty does not cover normal wear and tear, abuse or misuse of this product including damage from inclement weather conditions, such as wind, rain, or hail.

Under no circumstances, we will be liable or responsible for any incidental or consequential damages.





















All replacement products or parts will assume the remaining warranty of the original product. This warranty gives you specific legal rights. You may also have other rights, which vary from state to state.

It is your responsibility to read and save these instructions before attempting to set up your gazebo. We would also like to suggest that you follow these safety precautions, care and maintenance tips when using your gazebo.

- 1.** Never set up or continue to use in any rain, wind or storm conditions, especially lightning storms. Damage can occur to your gazebo and put you and others in potential danger.
- 2.** We suggest that you take your time in order to avoid bending the frame or pinching your fingers or hands while opening and closing the frame.
- 3.** Avoid setting up your gazebo on steep inclines.
- 4.** Do not use your gazebo for permanent shelter. It is designed for temporary use only.
- 5.** Keep your gazebo away from heat and flames at all time. Do not barbecue or build fires under your gazebo.
- 6.** Never leave your gazebo unattended.
- 7.** Never store your gazebo when it is wet or damp. Let it dry completely to avoid mildew.
- 8.** The frame **MUST** be staked or properly weighted down at all times.
- 9.** When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury or damage to equipment. Please read all instructions before assembly and use.
- 10.** Some parts may contain sharp edges. Wear protective gloves if necessary. Three or more people are recommended for safe assembly.
- 11.** Keep all children and pets away from assembly area.
- 12.** Begin assembly at least 9 feet from any obstruction such as fences, a garage, house, overhanging branches, laundry lines or electrical wires.
- 13.** Please sweep or keep this unit out of snow deeper than 10 inches.






PACKING INCLUDES

Parts List

No.	Parts	QTY.	No.	Parts	QTY.
A		1	F ₁		2
A ₁		1	G		4
B		1	H		2
B ₁		1	H ₁		2
C		2	I		2
D		1	I ₁		1
D ₁		1	J		2
E		1	J ₁		2
E ₁		1	K		3
F		2	K ₁		3












PACKING INCLUDES

Parts List

No.	Parts	QTY.	No.	Parts	QTY.
L		8	P		4
M		2	Q		4
O		2			

PACKING INCLUDES

Hardware

No.	Parts	QTY.	No.	Parts	QTY.
R		1	X	 M6x20	22
S	 M6x85	10	Y	 M6x12	8
T	 M6x45	2	Z	 M6x8	32
U	 M6x40	6	Z ₂	 M5x12	16
V	 M6x35	2	Z ₃		4
W	 M6x30	8			



SET UP THE GAZEBO


Step 1

Put the leg (A) on the foot pad (P) and fix it with 4 pcs screws (Z2), Repeat the above steps for the leg(A1).

Insert the tubes (O) into the cross connector (I1).

Connect the two tubes (F) into both ends of the cross connector (I1), fix them with 2pcs screws (V).

Connect tube assembly between the leg A and leg A1 with screws (S).




Step 2

Fix the tube (C) with screws (X) at the top of the leg(A),leg(A1);

Connect the cross bars (J1) on each leg with screw (W);


Use screws(X) to connect the steel triangle plate Q to legs (A), (A1)



SET UP THE GAZEBO


Step 3

Put the leg (B) on the foot pad (P) and fix it with 4 pcs screws (Z2), Repeat the above steps for the leg(B1). Fix the tube (C) with screws (X) at the top of the leg(B),leg(B1); Use screws(X) to connect the steel triangle plate Q to legs (B),(B1).



Step 4

Place the leg(B) and leg (B1) in place to connect the cross bars (J1) with screws(W)



SET UP THE GAZEBO


Step 5

Fix the tube (F1) at the bottom of the leg with screw (S)

Position tube (I) between the two steel triangle plates on leg(A), leg(B), and connect with 2 screws (X).


Place the mesh bar (J) above the crossbar (J1) and secure with screw (Y). Repeat the above steps for the other legs.

Install M on cross bars (C), fix it with screw (T), pay attention to the hole faces inward and the gap faces outward.



Step 6






The tube (G) and D1 is connected with the L-shaped connector (L) and fixed with the screws (Z). Repeat the above steps for the other tubes.



SET UP THE GAZEBO

Step 7


Put the PC board (K) into the tube(D1) and (G),install each of the other PC board and tube in turn. Repeat the above steps to the PC board assembly.



SET UP THE GAZEBO


Step 8

Place the assembled PC board assembly on the tube as pictured. Use the screw (U) to connect the tube E/E1 with the leg. Connect with the M bracket with the screws (U).



Step 9

Place the other assembled PC board assembly on the top as pictured. Use the screw (U) to connect the tube D/D1 with the leg, then connect D and E, D1 and E1 with the screw (X).



SET UP THE GAZEBO

Step 10

Insert a stake(Z3) into the foot of each gazebo leg.

