


# SIDE TABLE

## OPERATING INSTRUCTIONS

---



### **WARNING**

1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **Intended for residential use only.**

### **LIMITED WARRANTY**

# SIDE TABLE


## ASSEMBLY INSTRUCTIONS

### IMPORTANT NOTE:


1. Use hand tools only for assembly as power tools may cause damage.
2. Carefully remove any staples used for packaging.
3. Phillips Screwdriver also needed for assembly (not provided).

PART	QTY
1. Top Panel .....	1
2. Shelf .....	1
3. Side Frame .....	2
4. Crossbar .....	2
5. Cam Bolt .....	4
6. Cam Lock .....	4
7. Bolt .....	8
8. Allen Wrench (not shown) .....	1


### STEP 1



### STEP 2



### STEP 3



**Remove all parts from carton, separate by part numbers indicated on parts list, and verify part quantities.**

**STEP 1** Attach both Crossbars (4) to Side Frame (3) using two Bolts (7), **DO NOT FULLY TIGHTEN BOLTS (7)**. Attach Shelf (2) to Side Frame (3) using two Bolts (7), **DO NOT FULLY TIGHTEN BOLTS (7)**.

**STEP 2** Attach second Side Frame (3) to Crossbars (4) and Shelf (2) using four Bolts (7), **DO NOT FULLY TIGHTEN BOLTS (7)**.

**STEP 3** Carefully turn assembly to the upright position, **APPLY FIRM PRESSURE TO ALIGN & FULLY TIGHTEN ALL BOLTS (7)**. Screw four Cam Bolts (5) into Top Panel (1). Slide exposed Cam Bolts (5) into holes in Crossbars. Insert four Cam Locks (6) into Crossbars, **FULLY TIGHTEN CAM LOCKS (6)**.

**ATTENTION: MAKE SURE ALL BOLTS (7) & CAM LOCKS (6) ARE FULLY TIGHTENED BEFORE USING THIS PRODUCT.**