

Side Table


Instruction Manual

Mesa auxiliar


Manual de instrucciones

Table d'Appoint


Manuel d'Instruction




A X1




B X1




C X1



D X4



E X4



F X16




M6x20mm

G X4



M6x25mm


H X1



EN: : Partially tighten the screws (about 70%).

ES: : Apriete parcialmente los tornillos (aprox. 70 %).

FR: : Serrez partiellement les vis (à environ 70 %).






EN: : Fully tighten the screws.




ES: : Apriete completamente los tornillos.

FR: : Serrez les vis complètement.




Step 1





Step 2




Step 3



Step 4



Step 5



EN:

NOTE:

* Ensure all screws are fully tightened.

ES:

NOTA:

* Asegúrese de que todos los tornillos estén completamente apretados.

FR:

REMARQUE :

* Assurez-vous que toutes les vis sont bien serrées.

