
V2.0 03/2025 US

CHANDELIER INSTALLATION MANUAL


READ AND SAVE THESE INSTRUCTIONS



Models: #NJD30002

PRODUCT SPECIFICATIONS

Height:40"
Width: 30"
Canopy: 4.8"
Weight: 3
V/F:AC110V, 50/60HZ
Socket: E12
Wattage: 8-40W
Voltage: 85-265V




SAFETY PRECAUTIONS

Read and Save These Instructions

Safety Information
This chandelier is for indoor use only.
Please thoroughly read this manual before attempting to assemble, operate, or install the product.
WARNING
IMPORTANT: NEVER attempt any work until the power has been turned off.
Turn off the main power switch, remove the fuse, or turn off the switch that controls the main power to the room where the chandelier is placed before operating.
Turn the wall switch off before operating. If the lamp to be replaced has a switch or pull tab, turn it off as well.
Use only bulbs with the wattage limited in this chandelier.
CAUTION
Please contact a certified electrical contractor if you have any queries about how to install this chandelier or if it is not operating properly.
All parts must be used in accordance with the specifications outlined in these instructions. No parts can be replaced.
PREPARATION
Check that all parts are available before beginning assembly. Check the parts against the package contents and hardware contents lists. Do not attempt to assemble the product if any parts are missing or broken.


TOOLS REQUIRED

Ladder
Wire Strippers
Pliers
Wrench



PARTS LIST


Unpack your fan and check the contents. You should have the following:



PART	DESCRIPYION	QUANTITY	PART	DESCRIPYION	QUANTITY
A	8# screws	2	K	Lamp arm	3
B	Mounting plate	1	L	Sector lamp arm	3
C	Canopy	1	M	Socket E12	6
D	Collar nut	1	N	Candle tube	6
E	Screw collar loop	1	O	Fixture wire	1
F	Quick link	1	P	Connection nut	2
G	Hanging rod	1	Q	Connection box	1
H	12in Downrod	1	R	Hexagonal nut	6
I	Tube	1	S	Gasket	6
J	Round iron plate	2	T	Wire connector	6


INSTALLATION

Remove the Round iron plate (J) from the connection box (Q).
Remove the hexagonal nut (R) and gasket (S) from the lamp arm (K) and socket lamp arm (L), and gently push the lamp arm (K) and socket lamp arm (L) so that the threaded connection goes through the hole in the connection box, then secure it with the hexagonal nut (R) and gasket (S), and repeat the operation for all 6 sets.




WIRING DIAGRAMS

Firstly screw the 6 black light wires together and then screw the other 6 white light wires together; Secondly, connect the fixture wire (O) correctly: connect the black wire harness to the Hot fixture wire (Black or Parallel Cord round and smooth) and the white wire harness to the Neutral fixture wire(White or Parallel Cord “D” shaped and ridged); Clamp with plastic wire connectors (T) or electrical tape.




Put the round iron plate (J) on the connection box and fix it with tube (I).




MOUNTING SYSTEM INSTALLATION

NOTE: A 12" downrod (H) is included in the package of the chandelier. If your room is very high, you can use connection nut (P) to connect this 12" downrod (H) to the tube (I), and then refer to the instructions below; if you don't need it, you can proceed directly to the instructions below.
Pass the fixture wire (O) through the hanging rod (G) and tighten the stem to the tube.
Then pass the fixture wire (O) and ground wire (Bare copper) through the collar nut (D) and canopy (C).
Attach the mounting plate (B) to the outlet box. Rotate the screw collar loop (E) onto the connection nut of the mounting plate. Wrap ground wire from the outlet box around the green ground screw, and thread it into the hole on the mounting strap (B).




WIRING DIAGRAMS

Use the quick link (F) to connect the hanging rod (G) to the screw collar loop (E). Pass the fixture wire (O) and ground wire (Bare copper) through the screw collar loop (E) and connection nut.
Connect the Neutral (White) supply wire from the outlet box to the Neutral fixture wire (White or Parallel Cord “D” shaped and ribbed).
Connect the Hot (Black) supply wire from the outlet box to the Hot fixture wire (Black or Parallel Cord round and smooth).
Connect the Ground wire (Bare Copper) from the outlet box to the fixture Ground wire (Bare Copper).
Clamp in place with the plastic wire connector (T), wrap each connector with approved electrical tape for a more secure connection, and carefully tidy all wires.




CANOPY ASSEMBLY

Push the canopy (C) up to the top and secure it with the collar nut (D).



CANDLE TUBE ASSEMBLY

Secure the socket (M) by screwing it into the correct place on the lamp arm. Place the candle tube (N) on the socket (M), and install the bulbs (Please do not exceed the maximum recommended capacity on the socket, and bulbs are not included in the package).



CARE AND MAINTENANCE


Before cleaning this device, make sure the power is turned off.
Wiping the lamps with gasoline, alcohol, anti-poison, or other corrosive substances will DESTROY the lamps.

TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Fixture does not light.	1. Fixture may be wired incorrectly. 2. Worn or broken bulb.	1. Check wiring. 2. Replace bulb.


CANOPY ASSEMBLY

Push the canopy (C) up to the top and secure it with the collar nut (D).



CANDLE TUBE ASSEMBLY

Secure the socket (P) by screwing it into the correct place on the lamp arm. Place the candle tube (Q) on the socket (P), and install the bulbs (Please do not exceed the maximum recommended capacity on the socket, and bulbs are not included in the package).



CARE AND MAINTENANCE

Before cleaning this device, make sure the power is turned off.
Wiping the lamps with gasoline, alcohol, anti-poison, or other corrosive substances will DESTROY the lamps.

TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Fixture does not light.	1. Fixture may be wired incorrectly. 2. Worn or broken bulb.	1. Check wiring. 2. Replace bulb.