


ASSEMBLY INSTRUCTION


024-637 CECIL OVAL BACK UPH ARM CHAIR



5) Assembly is completed.

IMPORTANT NOTES :

- . Place all wooden parts on a clean and smooth surface such as a rug or carpet to prevent the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials, including staples and packing straps before you start to assemble.
- . Do not tighten all screws and bolts until completely assembled.
- . Keep all hardware out of the reach of children.



NO.	Dimension	Shape	Quantity
A	Bolt 5/16"*38mm		1pc
B	Bolt 5/16"*76mm		4pcs
C	Flat washer 5/16"*19mm		11pcs
D	Lock washer 5/16"		13pcs
E	Nut 5/16"		4pcs
F	Wrench 12mm		1pc
G	Allen Key 4mm		1pc
H	Bolt 1/4"*38mm		4pcs
I	Flat washer 1/4"*13mm		2pcs