


Assembly Manual





Accent Chair



.CAUTION

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Part list






A x 1  Left frame	B x 1  Right frame	C x 1  Seat cushion
D x 1  Back cushion	E x 1  Stretchers	

Thank you for purchasing our **SOFA**


Before you start, here are some helpful advice:

1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the sofa, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 20 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe and environmentally friendly way.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all pieces out of reach of children.
7. If you have any questions about the product: please send an email to our dedicated customer service email, and we will reply to your questions within 12 hours.


Hardware list

H 1x4  Bolt 01 1/4"x2-1/2"	H2x4  Bolt 01 1/4"x1-1/2"	H3x8  Spring washer
H4x4  Flat washer 1/4" (12mm)	H5x4  Flat washer 1/4" (19mm)	H6 x 1  Allen wrench
H7x4  wood plug	H8x2  Screw	


1




2




3




4



5



6



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.