


# Storage Shed



**BELLEZE®**

**FOLLOW US:**



@bellezefurniture

**CONTACT INFO:**

support@belleze.com  
1-800-682-6376

**ITEM NO. 014-HG-17035**

The instruction booklet contains **IMPORTANT** safety information. Please read it in full and keep it for future reference.

[www.belleze.com](http://www.belleze.com)

Scan this QR Code  
to view our online tutorial





Estimated time for assembly:

**60 mins**



Weight limitations are as follows:






Assemble the furniture on an empty carton, carpet, or rug to prevent scratches or damage.

For safety, please keep pets and children away from the assembly area.

Ensure the product is fully assembled before use. If you are missing any hardware or products, do not use it until you have restored the missing parts.



This furniture requires 2 people for assembly.

Read this instruction manual prior to assembly to familiarize yourself with the various steps.

Lay out all components and hardware separately on a flat surface and make sure that no parts are missing or damaged before assembly. Do not destroy or discard any packaging until you are certain that you have all the necessary parts for assembly.


Hand tight all hardware and careful not to over tighten to avoid damaging the product.

## CAUTION

There are small components used in the construction of this product. Loose items should be kept away from pets and children to avoid a choking hazard.

Keep all plastic bags and packaging film away from pets and children to avoid suffocation.

# PACKAGE CONTENTS



## PACKAGE CONTENTS

CODE	DESCRIPTION	QTY
A1	Bottom Right Side Panel	1
A2	Bottom Left Side Panel	1
B1	Upper Right Side Panel	1
B2	Upper Left Side Panel	1
C	Side Connection Panel	2
D1	Bottom Left Door Panel	1
D2	Bottom Right Door Panel	1
E1	Upper Left Door Panel	1
E2	Upper Right Door Panel	1
F	Door Connection Strip	4
G	Base Strip	1
H	Bottom Back Panel	1
I	Upper Back Panel	1
J	Gable End	1
K1	Left Roof Panel	1
K2	Right Roof Panel	1
L	Base Block	4
M	Roof Ridge	1
N	Bottom Panel	1
O	Storage Panel	3

# PACKAGE CONTENTS



60x + 5x



36x + 3x




10x + 1x




24x + 3x




10x + 1x




4x




1x




4x



2x



4x



2x




12x + 1x



Install all hardware perpendicular to the opening.

Required tools for assembly (Not included)




1





① 16x

Connect the bottom side panels (A1, A2) to the upper side panels (B1, B2) with side connection panels (C).



# 2

Insert wood dowels to the base strip (G), back panels (H, I), and the gable end (J).






# 3

Assemble the bottom back panel (H) between the side panels (A1, A2).




Note: The slope of the side panels has to point upward on the inside.



# 4


Assemble the base strip to the front of the shed assembly.



Note: Orient the front sticker to the front of the shed.


# 5

Assemble the gable end between the top of the upper side panels (B1, B2).





# 6

Assemble the upper back panel (I) to the shed assembly.





# 7

Attach base blocks (L) to the bottom of the shed assembly.




# 8

Attach adjustable feet levelers to the base blocks.




Put bottom panel (N) and storage panels (O) inside the shed.






# 10

Connect the bottom door panels (D1, D2) to the upper door panels (E1, E2) with connection strips (F).






# 11

Attach door hinges to the shed doors.



Attach doors to the shed.






# 13

Attach door handles and lock latch to the doors.




① 8x



⑦ 1x




⑨ 2x




# 14

Assemble roof panels (K1, K2) onto the top of the shed.





Attach roof ridge (F) on top of the roof.




Note: Make sure the gable end, roof and the ridge align in the middle.

Put the lock on the lock latch.






Adjust the foot leveler of the shed if necessary.



# 18-A

Affix the shed to the wall.




NOTE: This step is for shed affixing to a wall taller than the shed. For shorter wall, follow step 18-B.



# 18-B

Affix the shed to the wall.

NOTE: This step is for shed affixing to a wall shorter than the shed. For taller wall, follow step 18-A.




# 19-A

Secure the shed to the ground.




NOTE: This step is for shed installing on lawn.



① 8x



⑩ 4x



Insert screws into the top 2 opening.

## YOU'RE FINISHED!



# 19-B

Secure the shed to the ground.


NOTE: This step is for shed installing on concrete ground.



① 8x






② 8x



⑩ 4x




⑫ 8



Insert screws into the top 2 opening.


## YOU'RE FINISHED!



## Warning

Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with included anti-tipping device in order to prevent the furniture from tipping over.

Different wall materials requires different types of wall anchors or screws. Use a suitable wall anchors or screws for your specific wall in order to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of device to use, please contact a hardware store.



## Warning

Only place items on top of the product if they meet the recommended size and weight limits.

Climbing on, stepping on, or placing overweighted objects on the product may cause property damage and/or injuries.

Items placed onto this product must be resting on a support surface without hanging over the edges.

# BELLEZE®

## FURNITURE CARE AND MAINTENANCE

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of longevity, please follow the recommendations in this care and maintenance guide.



### MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly.
- Check the tightness of all bolts every 2 months and tighten them if necessary.



### CLEANING

- Clean the furniture surface with a lightly dampened cloth or soft brush.
- Regularly clean the cloth surface with a vacuum cleaner.
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol to clean the surface.

### ⚠ WARNING

The manufacturer and seller are not responsible for any and all liability relating to personal injury, property damage or losses, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification or neglect of this product.

© All copyright of this document belongs to BELLEZE.

This document may not be printed, translated, reproduced, or distributed in whole or in part without written permission from BELLEZE.

## WARRANTY

BELLEZE products come with a 1-year warranty from the date of delivery.  
**Register your product on our website to enjoy our limited lifetime warranty!**



## AFTER-SALE SERVICE



Encounter any difficulties or missing parts?



Contact us at **1-800-682-6376** or email us at **support@belleze.com**



We will send you replacement.



Hassle free!  
No need to worry about repackaging and sending your item back.

**We hope you enjoy your new BELLEZE furniture!**  
**Share your photos on Instagram and tag us: @bellezefurniture.**

---

### FOLLOW US:



@bellezefurniture

---

### CONTACT INFO:

support@belleze.com  
1-800-682-6376

---

**BELLEZE®**