


Kids Desk Set

Product ID. 7AZAN




Scan for Support
support@garvee.com



Distributed by
GARVEE.com


V260328FBEG

Exploded Drawing




Product Parts


A




B




C




D




E



F




G



H




I



J



K




L



2 pcs

2 pcs

M



N




O




P



Q




R



S



T



U



V



W



X



2 pcs

2 pcs


4 pcs

2 pcs


2 pcs

2 pcs


Y




Z



AA



AB



AC



AD




2 pcs

2 pcs

Hardware

1



M6*35mm

7 pcs

2



Ø4*35mm

55 pcs

3



Ø4*22mm

16 pcs

4



Ø4*28mm

2 pcs


5



M6*20mm

2 pcs

6



2 pcs

7



Ø15*10mm

7 pcs

8



Ø3*8mm

4 pcs

9



Ø3*12mm

12 pcs

10



2 pcs

11



Ø4*20mm

2 pcs

12



Ø4*14mm

2 pcs

13



Ø4*16mm

8 pcs

14



4 pcs

15



M6*40mm

8 pcs

16



Ø5*15mm


1 pcs


17



1 sets


Step 1

1  7 pcs
M6*35mm



Step 2


2  8 pcs
Ø4*35mm



Step 3


2  4 pcs
Ø4*35mm

15  8 pcs
M6*40mm




Step 4

2  8 pcs
Ø4*35mm



Step 5


- 4**  2 pcs
Ø4*28mm
- 3**  8 pcs
Ø4*22mm



x2 sets

Step 6


- 3**  8 pcs
Ø4*22mm



x2 sets


Step 7

- 8**  2 pcs
Ø3*8mm
- 6**  1 pcs




Step 8

- 2**  4 pcs
Ø4*35mm




Step 9

- 5**  2 pcs
M6*20mm




Step 10

- 11**  2 pcs
Ø4*20mm
- 12**  2 pcs
Ø4*14mm
- 9**  12 pcs
Ø3*12mm
- 10**  2 pcs




Step 11

- 2**  6 pcs
Ø4*35mm





Step 12

- 2**  9 pcs
Ø4*35mm




Step 13

- 2**  8 pcs **8**  2 pcs
 $\varnothing 4 \times 35 \text{ mm}$ $\varnothing 3 \times 8 \text{ mm}$
16  1 pcs **6**  1 pcs
 $\varnothing 5 \times 15 \text{ mm}$




Step 14

- 11**  7 pcs
 $\varnothing 15 \times 10 \text{ mm}$




Step 15



Step 16

- 2**  8 pcs
 $\varnothing 4 \times 35 \text{ mm}$



Step 17

13




4 pcs

14



4 pcs

Ø4*16mm




Step 18

13




4 pcs

Ø4*16mm



Step 19



WALL MOUNTING ASSEMBLY

For added safety and stability, it is recommended that the wall mounting hardware be installed. For safe mounting, it is essential to use wall anchors appropriate to your wall type (i.e. plaster, drywall, concrete, etc.). Mount to wood studs whenever possible.

Use a **1/4" (6.5mm)** drill bit to pilot the hole. If mounting to plaster, wood panels, brick or other drywall please consult a qualified professional.

Please make sure you use the right hardware for your wall type for your safety.

⚠ WARNING:
Do not install on a wall where items can fall off and injure a child.

⚠ WARNING:
CHOKING HAZARD, Unassembled parts may be choking hazard to children 3 years and younger.

⚠ CAUTION:
Adult assembly required.
Hardware contains small screws with sharp points.
Keep unassembled parts out of reach of small children.

Hardware

A. Screw x 1
M4x25mm



B. Small Washer x 2
Φ10XΦ5X1mm




C. Plastic Anchor x 1



D. Plastic Anchor x 1



The following tools (not included) are required for assembly:



Electric Drill

E. Wood Screw x 1
Φ4X32mm



F. Nut x 1



G. Large washer x 1
Φ16XΦ6X1mm



Wrench x 1



1/4" (6.5mm) Drill Bit




Phillips® Screwdriver

Step 1

Attach Plastic strip to back of product.

Hole predrilled in product backboard #J




Step 2 Use 1/4" (6.5mm) drill bit to drill hole in wall

Do not drill an oversized hole or the wall anchor will not hold tightly into the wall.

Tap wall anchor into hole.

Secure product to wall with screw "E" through Plastic strap and into wall anchor.



Warning:

Serious or fatal injuries can occur from furniture tip-over. To help prevent furniture tip-over:

Use provided mounting hardware to secure furniture to the wall.

This may reduce but not eliminate the risk of furniture tip-over.

Do not allow children to climb on furniture.

Keep remote controls, toys, and other items that might attract children off of this product.

Unless specifically designed to accommodate, do not set televisions or other heavy objects on top of this product.

GARVEE

support@garvee.com