

使用说明书

8DP2-A10/8DP3-A10系列



版本:1.0


产品简图




电源指示灯状态介绍

灯光常亮：蓝牙已连接
灯光慢闪：蓝牙未连接
绿灯：正常工作/充满电
红灯：开盖/缺纸/过热
黄灯：电量不足,请及时充电
黄灯快闪：充电中


打印纸安装说明



❶ 确保盖紧盖子




❷ 长按2秒开机




❸ 对准进纸口插入，直至被吸入无法拔出

(如果出现卡纸，请按滚轴拆装说明操作，取出纸)


滚轴拆装说明



❶ 打开盖子，按下滚轴右上方的金属按键



❷ 滚轴右侧弹起，向右侧抽出滚轴



❸ 滚轴两端放在金属支架上，向下按即可安装成功

App 下载（手机打印）

方式1:
在应用商店或App Store上搜索[爱印],
下载并安装APP。

华为应用市场　VIVO应用商店　Google Play

小米应用商店　腾讯应用宝　App Store

OPPO应用商店


方式2:
扫描下方二维码下载APP。

❶ iOS 系统：开启蓝牙，允许爱印（AiYin）App 获取访问权限。
　安卓系统：开启蓝牙与定位功能，允许爱印（AiYin）App 获取访问权限。
❷ 打开爱印（AiYin）App，连接打印机。
❸ 打印机连接上后，打开App提供的功能模块即可操作打印。

充电说明

- 5V⎓2A输入充电，建议使用手机充电器进行充电。
- 建议购买后第一次使用时请先充满电。
- 长时间未使用，请间隔3个月充一次电，以免锂电池长时间自然损耗无法充电。

清洗打印头



❶ 请关机后打开打印机盖子，拆卸滚轴，取出打印纸。

❷ 将棉布或者棉棒沾上医用酒精，沿着打印头中央到四周的方向轻轻擦拭。

❸ 清洁打印头后，不要立即使用打印机，请等候1~2分钟，待酒精完全挥发后方可使用。

警告

- 本产品出厂标配不包含电源适配器,若使用电源适配器充电，应购买使用获得CCC认证且满足标准的电源适配器。
- 如果换用不正确的型号的电池组会有爆炸的危险。
- 请不要将电池投入火中或加热炉中,请勿对电池进行机械挤压或切割进行处置。
- 请不要将电池放置在可能导致电池爆炸或泄漏可燃液体或气体的极高温度环境中。
- 请不要将电池放置在可能导致电池爆炸或泄漏可燃液体和气体的极低气压中。
- 在居住环境中，运行此设备可能会造成无线电干扰。



注意!
撕纸刀片有尖锐边缘，请小心勿触防止割伤。



注意! 热零部件!
打印完成后，请勿直接接触打印头，以防过热烫伤。关闭电源后等待半小时才能接触打印头。



此产品需在成人监护下使用。

保修卡

产品编号 _____

产品型号 _____

用户名称 _____

用户地址 _____

联系方式 _____

卖家名称 _____


购买日期 _____

报修日期	故障及处理	维修员

注：该保修卡仅限中国大陆地区使用


Instruction Manual

A10 Series



Version:1.0


Product Sketch




Power Indicator Status

- Light steady on:Bluetooth connected
- Light flashing slowly:Bluetooth disconnected
- Green light on:Normal use status /Full charged
- Red light on:Cover opened/No paper/Over-heat
- Yellow light on:Low battery,please charge in time.
- Yellow light flashing quickly:Charging


Paper Installation Instructions



❶ Ensure the lid is closed tightly




❷ Press and hold the power button for 2 seconds to turn on




❸ Align with the paper feed slot and insert until it is drawn in and cannot be pulled out

(If paper jam occurs, please follow the roller disassembly instructions to remove the paper.)


Roller Disassembly Instructions



❶ Open the lid and press the metal button on the top right of the roller



❷ The right side of the roller will pop up, then pull the roller out to the righ



❸ Place both ends of the roller on the metal brackets, and press down to install successfully

App Download (Printing with your phone)

Method 1:
Search for [AiYin] on Google Play
or App Store.

华为应用市场

VIVO应用商店

Google Play

小米应用商店

腾讯应用宝

App Store

OPPO应用商店

Method 2:
Scan the following QR code
to download App.

❶ i0S: Turn on Bluetooth,allow AiYin App to access.
Android: Turn on Bluetooth and Location,allow AiYin App to access.


❷ Open AiYin App and Tap device icon in the upper left corner,Connect the thermal printer device.

❸ Once the printer is connected, open the functional modules provided by the App to start printing operations.

Charging Instructions

- 5V⎓2A input, recommend to use mobile phone charger for charging.
- Recommend to charge the battery fully before using.
- If printer has not been used for a long time, please charge it every 3 months, to avoid long-term natural wear and tear of lithium batteries can not be charged.

Clean the Printer Head



❶ Please turn off the printer, open the printer cover, remove the roller, and take out the printing paper.

❷ Dip a cotton cloth or cotton swab with medical alcohol, and wipe gently along the center to the periphery of the printer head.

❸ After cleaning the printer head, do not use the printer immediately. Please wait for 1 to 2 minutes, use the printer after the alcohol has completely evaporated.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

物料编码：B34600002-E
物料名称：A10说明书（中性 中英双语）
尺寸：120*69mm
材质：80g哑粉纸
装订方式：骑马钉单钉
印刷：四色印刷
版本：1.0
日期：25.12.26