
INSTALLATION INSTRUCTIONS


DeerValley®

Bathtub Shower Door



www.deervalleybath.com | (312) 626-9466 | service@deervalleybath.com

Product Breakdown Diagram



If you have any questions or concerns please contact us:

(312) 626-9466
service@deervalleybath.com

Delivery Notes

Upon receiving the product, please immediately inspect for any transportation damage, missing parts, or manufacturing defects.









Cleaning and Maintenance

1. For daily cleaning of the glass panel, you can use common liquid detergent and a soft cloth.
2. For stains, use a clean soft towel or a small amount of neutral soap solution or toothpaste to gently wipe.
3. To keep the glass surface shiny, you can use a polishing agent for polishing treatment.


Precautions


1. Do not use acidic, alkaline, or sharp tools during cleaning to avoid damaging the glossiness of shower trays, glass, metal materials, and other accessories' surfaces.
2. Avoid using strong detergents containing acetone or ammonia ingredients; when disinfecting, avoid using disinfectants containing formic acid and formaldehyde to prevent damage to the product's surface glossiness.
3. Do not allow body or hard objects to come into contact with or impact the glass surface during showering to avoid accidents.
4. Regularly check the usage condition of the product, and if any abnormalities are found, please contact the after-sales service department promptly.

Tool List (Not Included)


Material Name	Illustration	Material Name	Illustration
Spirit Level		Power Drill	
Ø3 Drill Bit		Ø6 Drill Bit	
Silicone Sealant		Rubber Hammer	
Tape Measure		Screwdriver	
Pencil		Hanging Hammer	

(312) 626-9466
www.deervalleybath.com






If the size of the upper track is too long, it can be cut to fit




Cut off the size of the upper track and also cut off the corresponding size of the lower track

(312) 626-9466
www.deervalleybath.com


Package Content




Track




Pulley




left wall material




Movable glass




Buffer rubber strip




Handle



Lower Rail




Lower slider




right wall material


Hardware Content




Decorative cover



ST4*10



Expansion tube φ6





ST4*30

Drawings may not exactly define contour of the product.


(312) 626-9466
www.deervalleybath.com

Installation Steps






∅6 Drill Bit



cc Expansion tube φ6




right wall material | left wall material | Expansion tube φ6


Step 1-Lay out parts labeled C, I, and cc.
Step 2-Position side frames C and I at the installation area and mark the hole locations.
Step 3-Drill with a 6 mm (1/4 in.) bit and insert the cc expansion anchors.
Step 4-There are 6 holes in total across both sides and 6 screws; ensure the positions are correct, plumb to the floor, and parallel to each other.

Drawings may not exactly define contour of the product.


(312) 626-9466
www.deervalleybath.com

Installation steps







Buffer rubber strip




Lower Rail



Decorative cover



ST4*10



ST4*30


Step 4-Lay out parts E, G, aa, bb, and dd.
Step 5-Align the installed side frames with the wall holes.
Step 6-Place bottom frame G on the tub rim, taller edge facing out.
Step 7-Align side frames C/I with the drilled holes to position G (G sits between C and I).
Fasten with bb screws, then cover with aa caps.
Step 8-Place gasket E over each hole and secure with dd screws—3 per frame.
Step 9-Repeat on the opposite side frame.


Drawings may not exactly define contour of the product.

(312) 626-9466
www.deervalleybath.com


Installation steps

Pay attention to the direction of installing the top rail.





Track



ST4*10


Pay attention to the direction of installing the lower track.


Step 10-Take top frame A and the remaining two bb screws.
Step 11-Fit A over the two mounted side frames; ensure correct orientation.
Step 12-Fasten from the back of A with the bb screws.


Drawings may not exactly define contour of the product.


(312) 626-9466
www.deervalleybath.com


Installation steps












Pulley




Movable glass

Step 13-Remove 4 roller assemblies (B) and 2 glass doors (D).
Step 14-Disassemble each roller screw; keep 1 washer and 2 clear screw sleeves per roller.
Step 15-Insert the sleeves into the top holes of each glass door—4 per door.
Step 16-Align washer and roller to each hole; washer must sit between metal roller part and glass.
Step 17-Tighten the screws.

Drawings may not exactly define contour of the product.

(312) 626-9466
www.deervalleybath.com

Installation Steps




Step 18-Hang both doors onto the top track.
Step 19-Ensure roller orientation: one inside, one outside.
*If needed, fine-tune roller height so the doors sit at the correct sliding level.


Drawings may not exactly define contour of the product.


(312) 626-9466
www.deervalleybath.com

Installation Steps




If the inclined movable door can adjust the upper wheel correction.






Adjust the sliding door and move the slider to the middle position.



Handle




Lower slider

Step 20-Disassemble handle set F.
Step 21-Slide the integrated bottom guide H to the center of bottom frame G.
Step 22-Seat both glass doors into the guide channel.
Step 23-Install handles F—one inside, one outside—ensuring the soft gasket sits between metal and glass.


Drawings may not exactly define contour of the product.

(312) 626-9466
www.deervalleybath.com

Installation Steps



Apply waterproof silicone sealant inside and outside.



Step 24-Apply silicone sealant to secure the frames; also bond soft guide H.
*Do not run or use water for 24 hours.

Drawings may not exactly define contour of the product.

(312) 626-9466
www.deervalleybath.com

DeerValley®

FIVE YEAR LIMITED WARRANTY

Phone: (312) 626-9466
Email: service@deervalleybath.com
Web: www.deervalleybath.com

LIMITED WARRANTY COVERAGE

5-YEAR LIMITED WARRANTY

DeerValley products are made with quality materials and excellent craftsmanship to provide customers with a long-lasting product. If any defects in materials or craftsmanship are found under normal use within the 5th year of delivery, DeerValley will provide replacement parts at no charge or, at its option, replace any product or part of the product deemed defective under normal installation, use, service, and maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required to process any claims. SCRATCHES ARE NOT COVERED UNDER WARRANTY.

The manufacturer warrants that this product will be free from manufacturing defects for the duration of the above-mentioned warranty period. Please retain a copy of the original invoice as proof of purchase.

DeerValley will, at its option, (1) repair or replace the defective part(s) or product(s) at no charge; (2) issue a refund for the original purchase price of the product(s) (valid within 30 days from the date of delivery); or (3) issue a credit to be applied toward the purchase of a new DeerValley product. Shipping/delivery charges may apply and are at DeerValley's sole discretion.

DeerValley recommends that installations be performed by a licensed, professional plumber. DeerValley will not be held responsible for any damage or product failure resulting from improper installation, misuse, or failure to hire a licensed professional. Additionally, DeerValley is not responsible for any removal or installation costs.

This limited warranty does not cover goods that have been subjected to accidents, negligence, improper installation, product abuse, product misuse, or the use of cleaners containing abrasives, alcohol, or other organic solvents. Such exclusions apply regardless of whether the actions were performed by a contractor, service company, or the purchaser.

DeerValley's responsibility under this limited warranty is limited solely to the replacement of parts and does not cover any other costs. DeerValley will not be responsible for labor charges or any damage incurred during installation, repair, or replacement, nor for any indirect, incidental, or consequential damages, losses, injuries, or costs of any kind related to this product. Except as required by law, this limited warranty replaces and excludes all other warranties, conditions, and guarantees, whether expressed or implied, statutory or otherwise, including but not limited to those regarding merchantability or fitness for a particular purpose.

RESPONSIBILITIES OF OTHERS

It is the responsibility of the installer or building contractor, acting on behalf of the user, to inspect the unit prior to installation. They are responsible for ensuring that the unit is free from defects or damage. Notices are placed on and within the unit, as well as on the shipping carton, to inform the installer of their responsibility.

If a problem is identified, the unit must not be installed. DeerValley is not responsible for failures or damage that could have been identified, repaired, or prevented through proper inspection and testing prior to installation.

Damage occurring during transit is the responsibility of the carrier. The user or installer must open the crate and inspect the unit for damage upon delivery. If damage is discovered, it must be reported immediately to the seller and the carrier in writing, and an inspection must be requested. If the carrier fails to respond, the issue should be reported to both the seller and the carrier. Freight claims should be filed promptly thereafter.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover negligence, misuse, abuse, improper installation, carelessness, accidents, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages resulting from improper maintenance, alteration of the product, or failure to follow the care or installation instructions provided with your product. The warranty becomes void if the DeerValley product is altered or if repairs are attempted using unauthorized accessories or parts not provided by DeerValley.

DeerValley is not liable for the loss of use of its products, inconvenience, or any other incidental or consequential costs, expenses, or damages. Please note that some states do not allow the exclusion or limitation of incidental damages.

DISCLAIMER

Except as expressly stated, no warranties or obligations, whether express, implied, oral, or statutory, are provided. No dealer or other individual has the authority to make any warranties or representations regarding DeerValley or its products. DeerValley shall not be held responsible for any such unauthorized warranties or representations.

WARRANTY SERVICE

NOTE: When requesting warranty service, please ensure you have the following:

- A copy of the original invoice
- Date of installation
- Description and pictures of the defect
- Model number or product description

To obtain warranty service or replacement parts, contact DeerValley Customer Service. DeerValley will determine whether to repair or replace the product, issue a refund, or provide a credit.