


ASSEMBLY INSTRUCTION SHEET FOR COUNTER TABLE (BUTTERFLY EXTENSION 18" INCH)


STEP - 1

Turn the dining table with top upside down




STEP - 3

Insert the bolt with metal washer & use the wrench to tighten the bolt at corner. Repeat step 2 & 3 for other corners.




STEP - 2

Layout the top & legs. Coordinate the numbers on leg & L" bracket of top. Align the holes on legs with holes on L" bracket.




ASSEMBLED VIEW





ASSEMBLY INSTRUCTION SHEET FOR COUNTER TABLE (BUTTERFLY EXTENSION 18" INCH)

STEP - 4

Pull left & Right side
sliding tops of the table
away from the centre.



ASSEMBLED VIEW



SIZE : 42" X 42" X 36" INCH

S.N.	PART LIST	QTY.
1	TOP	1
2	LEG	4
3	BOLT	12
4	METAL WASHER	12
5	WRENCH	1