

ASSEMBLY INSTRUCTIONS



Dining Table

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





- 1. Don't attempt to repair or modify parts that are broken or defective .Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)		B2 (BOX 2)		
A TOP		1PC		
		B POST		1PC
		C BOTTOM FRAME		1PC
		D MOUNTING PLATE		1PC

HARDWARE IDENTIFICATION


Z	HARDWARE PACK	Hardware pack	
1	ALLEN WRENCH M10-SR		1PC
2	ALLEN WRENCH M6-SR		1PC
3	ALLEN WRENCH M5-SR		1PC
4	BOLT M12" *80MM-BLK		1PC
5	BOLT M8" *30MM-BLK		3PCS
6	BOLT Ø5/16" *15MM-RBW		4PCS
7	LOCK WASHER Ø17 *Ø 13-SR		1PC
8	FLAT WASHER Ø17 *Ø8.3-SR		7PCS
9	WASHER Ø5/16 *15MM-SR		1PC

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4



ASSEMBLY INSTRUCTIONS



Note :Dimension tolerance $\pm 5\%$

