

Assembly Instructions

CAUTION

- The Gravity Chair is designed to support a maximum of 250lbs (113kg).
- Do not hang from the overhead dowel.
- Do not swing.


1. Make a loop and knot through the large S-hook (A). Using the eye bolt, secure to a ceiling joist capable of holding at least 250lbs. Always ensure that the chair is hung at least 12" off the floor or ground.

Make sure all wooden dowels are inserted completely into dowel holders!
(As shown in Fig 1)



Fig 1

H



2. Insert all dowels completely into the proper dowel holders: the longest dowel overhead (B); two equal length dowels for the armrests (C); the short dowel for the footrest (D).

3. Loop the cup holder (E) through webbing and pull through on the overhead dowel (B). Tie the footrest (F) to the small 'S' hook and insert into eye bolt. Adjust the length so that it hangs just below the bottom of the seat of the chair.



Eye Bolt



Small 'S' Hook



Large 'S' Hook

Washing and Care:

Using a soft brush and warm soapy water, scrub where necessary. Allow to dry on a flat surface or by hanging. The material is NOT suitable for washing machine, tumble dryer or chemical bleaches.