


### IMPORTANT NOTE:

- .To prevent scratch, place all wooden parts on a clean and smooth surface such as carpet.
- .Keep all hardware parts out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	Backrest	1pc
B	Chair Leg	4pcs
C	Footrest	1pc
D	Apron with swivel plate	1pc
E	Cushion seat	1pc
F	(Left/Right) Armrest	2pcs

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC Screw M6x30mm	4pcs
2	JCBC Screw M6x35mm	12pcs
3	JCBC Screw M6x45mm	12pcs
4	Spring Washer M6x10mm	24pcs
5	Flat Washer M6x13mm	6pcs
6	Flat Washer M6x16mm	22pcs
7	Allen Key Small M4	1pc
8	Wooden plug Ø14	2pcs




**NOTE:** Do not tighten all screws until the stool is fully set-up.


STEP:1



STEP:2



STEP:3



STEP:4

