


# COMPUTER DESK

## ASSEMBLY INSTRUCTIONS



### **WARNING**

1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.

### **LIMITED WARRANTY**


We Warrant to the original purchaser its products to be free from defects in material and workmanship for a period of 90 days. Defects and damage from misuse, abuse, negligence, alteration, accident, vandalism, rusting, acts of nature or any other event beyond the control of us is not covered. The warranty does not cover cosmetic damage that may result from normal use. Liability for incidental or consequential damages is excluded. The user assumes all risk of injury resulting from use of this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

To make a warranty claim, contact Customer Service, provide model number, sales receipt and description of the problem. It is the customer's responsibility to prepay freight on any components returned to the factory. We will pay return freight on components covered under terms of warranty.


Our quality standards are among the highest in the industry. Sometimes, no matter how hard we try, there are times when hardware is missing. Our Parts Department will do everything possible to promptly remedy the problem.




## PARTS LIST




(1) Top Panel (1 PC)




(2) Left Side Panel (1 PC)




(3) Right Side Panel (1 PC)




(4) Left Wood Leg (1 PC)




(5) Right Wood Leg (1 PC)



(6) Metal Post (2 PCS)




(7) Left Bottom Panel (1 PC)




(8) Right Bottom Panel (1 PC)




## PARTS LIST




(9) Back Panel (1 PC)




(10) Cross Bar (1 PC)




(11) Drawer Bottom (1 PC)



(12) Left Drawer Side (1 PC)















(13) Right Drawer Side (1 PC)




(14) Drawer Back (1 PC)


## HARDWARE LIST

NO	SKETCH	DESCRIPTION	SIZE	Q'TY
A		Cam Bolt		8 PCS+ 1 EXTRA
B		Cam Lock		8 PCS+ 1 EXTRA
C		Wood Dowel	ø8 X 40 mm	2 PCS
D		Bolt	ø1/4" X 35 mm	4 PCS+ 1 EXTRA
E		Bolt	ø1/4" X 25 mm	4 PCS+ 1 EXTRA
F		Bolt	ø1/4" X 13 mm	8 PCS+ 1 EXTRA
G		Wrench	4 mm	1 PC
H		Screw	M4.2 X 32 mm	18 PCS+ 3 EXTRA
I		Screw	M3.5 X 13 mm	12 PCS+ 2 EXTRA
J		Ball Bearing Slide		2 PCS
K		Handle		1 PC
L		Bolt	ø5/32" X 38 mm	1 PC


STEP 1




STEP 2



### STEP 3




### STEP 4







## STEP 5




## STEP 6



## STEP 7




## STEP 8






## STEP 9



## STEP 10



## STEP 11

