



1803-4 Acrylic Podium Instructions

Video ins link: <https://www.fixturedisplays.com/video/1803-4.AVI>


<https://youtu.be/n5VWMck0QIs>



1. Fasten 5 legs to base with 10 M6*20mm screws.




2. Fasten top panel to legs with 5 M6*20mm screws.




3. Fasten 2 support panels to top panel with 4 M4*12mm screws. Fasten reading panel with 4 M4*12mm screws. Fasten stopper with 3 M4*12mm screws.


**Search these part numbers on
www.fixturedisplays.com for other
items you may also like: 11461, 11462,
14301, 11460, 19240**




11461




11462



14301



11460



19240

We are here to help. Contact us for any issues before filing returns. God bless. cs@fixturedisplays.com