Assembly Instructions

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

COMPONENT LIST:

FIGURE	DESCRIPTION	QTY
	Hardware Bag	1 pce
	Chair Back	1 pce
	Right Leg Assembly	1 pce
	Left Leg Assembly	1 pce
	Center Stretcher (Long)	1 pce
	Center Stretcher (Short)	1 pce

HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1	0	JCBC Bolt	10 pcs
2		Lock Washer	6pcs
3	0	Flat Washer	6pcs
4		Allen Key	1pce
5		JRN Nut	4pcs
6	0	Wood Plug	4pcs

This product will take 15-20 minutes to assemble.

Reminders

- 1.Use only the hardware supplied.
- $2. \\ \mbox{Once the product is assemble, level and tighten all the bolts.}$
- 3.Do not over-tighten bolts.
- 4. This item may require periodic tightening

NOTE:

- 1.Two or two people are needed for assembly
- 2 please keep all hardware parts out of the reach of children.




PAGE 1 OF 2

Assembly Instructions

ASSEMBLY:

STEP 1

- 1.1-Insert the center stretcher into the **RIGHT AND LEFT LEG ASSEMBLY**. Make sure its JRN NUT holes are facing down. Insert a **JRN NUT** into the center stretchers hole and position it with a screw driver.
- 1.2-Insert the JCBC BOLT through the RIGHT AND LEFT LEG ASSEMBLY into each of the center stretcher. Hand tighten using the provided ALLEN KEY Do not fully tighten bolts yet.



STEP 2

- 2.1- Attach the CHAIR LEG ASSEMBLY (left and right) to the CHAIR BACK using LOCK WASHERS AND FLAT WASHERS, JCBC BOLTS and hand tighten with ALLEN KEY.
- 2.2- Once chair is balanced fully tighten all bolts.

Fig.2

2.3- Cover the holes located in the RIGHT AND LEFT LEG ASSEMBLY with the WOOD PLUGS provided.

Allen
JCBC
Bolt
Flat
Washer
Lock
Washer
Vour furniture will appear cloudy or streaky if oil

based or wax based polishes are interchanged. Spray your furniture surface evenly. Wipe in a

circular motion with a soft clean cloth.