


ASSEMBLY INSTRUCTION













WF310720AAA

WF310721AAA


WF310722AAA

WF310723AAA







PARTS - WF310720AAA



Loveseat & console x 1PC




Side backrest x 1PC




Backrest x 1PC


D is in the bottom of A,
please see **STEP1**



Console back x 1PC




Ear x 1PC




Power adapter x 1PC

WF310721AAA




Corner seat x 1PC

WF310722AAA




Left corner backrest x 1PC




Right corner backrest x 1PC


PARTS - WF310723AAA




Loveseat x 1PC




Side backrest x 1PC



Backrest x 1PC




Ear x 1PC




Power adapter x 1PC


STEP 1: Take D out of the bottom of A, as shown.




STEP 2: Insert B, C, D to A, as shown.




STEP 3: Insert E to B, as shown.




STEP 4: Insert B, C to J, as shown.




STEP 5: Insert E to B, as shown.




STEP 6: Insert H, I to G, as shown.



STEP 7: Insert A & J to G, as shown.



STEP 8: Insert F to Sofa, as shown. The switch controls the light under the seat; and the USB charging port is inside the console.



COMPLETED

