


# ASSEMBLY INSTRUCTIONS



**+ Do Not Use Power Tools**



**+ Suggested Adults**



## NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

## 1 IMPORTANT SAFETY INFORMATION


- Do not** assemble the product if the parts arrived damaged.
- Do not** assemble if Hardware parts are missing.

## 2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

## + Parts Included

- ① Leg frame (1 pc)




- ② Seat frame (1 pc)



## + Parts Included

- A. Bolt  
Ø8x45mm (4 pcs)




- B. Spring Washer  
Ø8xØ13mm (4 pcs)



- C. Flat Washer  
Ø8xØ19mm (4 pcs)




- D. Allen Key (1 pc)



# ASSEMBLY INSTRUCTIONS

①



②

