

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



PARTS IDENTIFICATION

A	TRAY		2PCS
В	DRAWER FRONT PANEL		1PC
С	DRAWER LEFT PANEL		1PC
D	DRAWER RIGHT PANEL		1PC
E	DRAWER MIDDLE PANEL		2PCS
	PAGE	2 OF 10	

PARTS IDENTIFICATION


F DRAWER BACK PANEL




G DRAWER BOTTOM PANEL



H LEFT FRAME



I RIGHT FRAME



J CROSSBAR



K LEFT SLIDE RAIL



PARTS IDENTIFICATION

L RIGHT SLIDE RAIL



1PC

M CASTER



2PCS

N CASTER-LOCK



2PCS

z HARDWARE IDENTIFICATION

1 CAM BOLT (38mm)



4PCS

7 LONG BOLT (1/4" x 38mm BLK)



6PCS

2 CAM LOCK (ø15mm)



4PCS

8 LONG SCREW (8 x 32mm)



8PCS

3 WOOD DOWEL (8 x 30mm)



4PCS

9 STICKER



8PCS

4 SMALL BOLT (3/16" x 12mm)



4PCS

10 GLUE



1PC

5 SHORT SCREW (3.5 x 12mm)



4PCS

ALLEN WRENCH (4mm)



1PC

6 SHORT BOLT (1/4" x 25mm BLK)



8PCS

12 HEXAGONAL KEY (8mm)




1PC

PAGE 4 OF 10


11

STEP 1


Do not tighten until each step is completed or instructed.




STEP 2



ASSEMBLY INSTRUCTIONS STEP 3




STEP 4




PAGE 6 OF 10


STEP 5




STEP 6




ASSEMBLY INSTRUCTIONS STEP 7




STEP 8



ASSEMBLY INSTRUCTIONS STEP 9



STEP 10 COMPLETE



PAGE 9 OF 10

Product Size: 1022 X 438 X 857 H (MM)

Product Size: 40.25" X 17.25" X 33.75"

