WALNUT NIGHTSTAND

ASSEMBLY INSTRUCTIONS

Read instructions carefully. See hardware and furniture part list for guidance. Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

| | PART LIST | |
|------|-------------|-------|
| ITEM | DESCRIPTION | QTY |
| Α | LEGS | 4 PCS |
| В | NIGHTSTAND | 1 PC |

| | HARDWARE LIST | |
|------|---------------------------|-------|
| ITEM | DESCRIPTION | QTY |
| 1 | JCBC BOLT M6 x 60mm | 4 PCS |
| 2 | M6 Flat Washer | 4 PCS |
| 3 | M6 Spring Washer | 4 PCS |
| 4 | M4 ALLEN KEY (BALL SHAPE) | 1 PC |

- CAUTIONS: 1. Do not FULLY TIGHTEN the nuts or bolts until all nuts autil all are loosley assembed.
 - 2. Do not OVER TIGHTEN the nuts or bolts. This causing damage to the threads.
 - 3. Keep all hardware parts out of reach of children.

