

Thank you for your purchase!



Indoor/Outdoor Poly Resin Rocking Chair

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:


CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE



Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.


A	 Seat	1pc	1	 Hex Bolt M6.3x60	16pcs
B	 Back Plate	5pcs	2	 Bolt M4.2x60	6pcs
C	 Right Arm	1pc	3	 Allen Wrench 5#	1pc
D	 Left Arm	1pc	4	 Phillips Screwdriver	1pc
E	 Runner	2pcs			
F	 Front Support Pole	1pc			
G	 Back Support Pole	1pc			



STEP:1



STEP:2



STEP:3

