
ASSEMBLY & CARE GUIDE

Solid Wood Double-Layer Single Rod Garment Rack

Item No. 1104



Before You Begin

- Confirm all parts and hardware are present before assembly.
- Assemble on a clean, flat surface to protect the wood finish.
- Follow the steps in order and tighten fasteners securely.
- Keep small parts and hardware out of the reach of children.

Safety & Use

During Use

- Do not jump on the rack or use it as a step/platform.
- Use only on a flat, stable surface to reduce tipping risk.
- Use the product only for its intended storage purpose.

Care & Inspection

- Stop using the product if any part is damaged or deformed.
- Check the product carefully about every 3 months.
- Do not attempt unauthorized repairs or modifications.

Pre-installed parts note: Any item marked as “Installed” in the source parts/hardware list is pre-installed in the finished product and is not packed separately in the hardware package.

Parts & Hardware Checklist

Lay out the components before assembly. Match each item to the number below.

No.	Part	Specification	Qty
1	Upper Long Side Panel	875 x 40 x 20 mm	1
2	Upper Short Side Panel	815 x 40 x 20 mm	1
3	Lower Side Panel	875 x 40 x 20 mm	2
4	Hanging Post	70 x Ø30 mm	5
5	Shelf Board	400 x 240 x 20 mm	1
6	Clothing Rod	400 x 35 x 20 mm	1
7	Metal Sleeve	80 x 40 x 20 mm	2
8	Base Plate	480 x 300 x 20 mm	1

Hardware

No.	Part	Specification	Qty
9	Straight Repair Screw	M7 x 50 mm	11 (incl. spare)
10	Metal Sleeve Screw	M6 x 25 mm	5 (incl. spare)
12	Allen Wrench	M4 x 70 mm	1

Assembly Overview

1

Build lower frame

Base + lower side panels + shelf

2

Join upper frame

Connect upper and lower side panels with sleeves


3

Install rod & hooks


Attach the clothing rod and five hanging posts

Assembly Instructions

Step 1 - Build the Lower Frame




Secure each Lower Side Panel (3) to the Base Plate (8) using Straight Repair Screws (9).



Secure the Lower Side Panels (3) to the Shelf Board (5) using Straight Repair Screws (9).

Step 2 - Connect the Upper and Lower Side Panels



Connection sequence


- Slide each Metal Sleeve (7) onto the lower panel tenons.
- Insert the Upper Long Side Panel (1) and Upper Short Side Panel (2) into the Metal Sleeves (7).
- Fasten each Metal Sleeve with the Metal Sleeve Screws (10).

Tight-fit note

If the upper/lower panels fit tightly, slide the sleeve onto the tenons first, then press the upper panels downward firmly until the tenons are fully inserted.

Final Assembly & Care

Step 3 - Install the Clothing Rod and Hanging Posts




Finish the upper frame

• Secure Clothing Rod (6) between Upper Panels (1) and (2) using Straight Repair Screws (9).

• Screw all five Hanging Posts (4) into the designated holes on the Upper Panels (1) and (2).

• Check that all fasteners are secure and the rack stands flat and stable.



Installation Complete

Place the garment rack on a flat surface. Recheck all screw connections before loading the rack with clothing or accessories.

Care Instructions

• Stop using the product if it becomes damaged or deformed.

• Inspect components about every 3 months for looseness or safety concerns.

• Do not repair or modify the structure in a way not described in this manual.

After-Sales Information

• For quality issues, missing accessories, or installation difficulties, contact your customer service channel.

• Dispose of packaging materials appropriately.

• Damage caused by natural disasters, improper repair, or unauthorized modification is outside the stated responsibility in the source manual.

Product Information

• Product: Solid Wood Double-Layer Single Rod Garment Rack

• Item No.: 1104

• Origin: China

• Quality Grade: Qualified