


SOFA BED

ASSEMBLY INSTRUCTIONS

MODEL NO.: RYS101A




INSTALLATION VIDEO

Please scan QR code with iOS or Android phone camera,
click the link to play the installation video.




If QR code is damaged, please contact us to get installation video.

If no access for cell phone scanner, please try other APP.




Thanks for your purchasing.

- Please read the instruction completely before assembly.
 - Please do not throw away any of the packaging or the instruction until you have all the components and when the furniture is fully assembled.
 - Considering the size and weight of the sofa, we recommend two adults to assemble the sofa, on a carpeted or padded area.
 - Keep all components and packaging out of reach of children or animals to avoid risk of choking or suffocation.
 - Please keep children away from plastic bag or any small pieces of stuff.
 - Cushions should be regularly maintained for perfect use.
 - 2 people to install is recommend.
 - 2 people to lift the sofa if you want to move it, do not push or pull directly
 - You can assemble it with out packaging tools or home electric drill, as shown below, Electric Drill tool is not included.
- Electric drill will improve your assembling efficiency.
You can use it if you have this tool, DO NOT overtight to prevent from damaging screws and slats/boards.




Components:




PART LIST & HARDWARE



A x2PCS




B x2PCS



C x2PCS



D x4PCS



E x2PCS




F x20PCS




G x1PC


Step 1 Please take out the armrest, pillows, legs and hardware from bottom of the sofa.




Step 2 Assemble the legs.



Step 3 Insert the armrest.



Step 4 Put the pillows on sofa, and the assembly is finished.



Step 5 Convert to sofa bed.
The back has 3 angles for adjustable.
The back must be adjusted more than 90° to lie flat.

Notes:

When the back was in upright position ①/② ,
please gently shake the backrest to check if
both sides are locked securely.

If one side is loose, lift the backrest 5~10
degree higher until you
hear a “click”.

