


Assembly Instructions

- 1. Place all the pieces on the floor
- 2. Connect the crossbar with the bases, screw the bolts tightly into place
- 3. Connect the hammock frame bar with the bases, screw the bolts tightly into place
- 4. Put the hook and washer in the appropriate hole to suit hammock size
- 5. Screw the wingnut to fix the hook
- 6. Hang the hammock according to the photograph (right)- hammock should only have a slight curve when first fitted to accommodate weight. Adjust as cotton stretches.
- 7. **WARNING. Do not leave children unattended while on the hammock. Not to be used as a swing. Always enter your hammock in the middle. Do not sit past the base legs. Regularly check hook and wingnuts are tight.**
- 8. **Inspect the hammock and frame regularly for deterioration or damage. Do not use if worn or damaged**



Components

Base	2 pieces	Hook, Washer & Wingnut	2 pieces
Crossbar	1 piece	Bolt	5 pieces
Hammock Frame Bar	2 pieces	Camping Carry Bag	