

Manual

Notice

Read this assembly manual carefully, and verify that you have all the parts listed before you begin. Keep your assembly manual for future reference.


Protect finishes by placing furniture pieces on a soft carpeted surface during assembly.

Do not place very hot/cold objects on top of any surface. Always use a coaster or mat. Never leave liquids on the surface: Clean immediately with a mild soap and a damp cloth. Never use scouring powder based cleanser. Don't touch the glass surface with a hard/acute object it may cause the glass to shatter.

DO NOT ASSUME CHILD SAFETY WITH ANY PIECE OF FURNITURE!

Do not allow children to climb on furniture. Improper use can cause death or serious injury. If you are placing a TV on top use safety straps on your TV to prevent the risk of a toppling television. Furniture straps fastened to a wall can also be used to help ensure safety.

Damaged parts or furniture put together incorrectly can lead to serious injuries. Make sure to follow instructions correctly.




Parts list

A. x4



B. x2




C. x2




D. x4




E. x1




1



2



3



IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE

WARNING Children must stay away from the assembly zone, preventing children from potential asphyxia because of plastic bag and foam breathing in nose;

WARNING For your safety, please do not tread or climb product.

WARNING The loading weight of seating shall be within the range that vendor claims.

WARNING The product is designed for adults use, domestic use and indoor use only.

WARNING The product shall not combine with other product for use.

WARNING If the product with seat height adjustments with energy accumulators that only trained personnel may replace or repair seat height adjustment components with energy accumulators

WARNING check regularly that all assembly fastenings are properly tightened, do not use the product if any structural part is broken or missing

WARNING Incorrect installation and incorrect use can cause accidents. Please completely follow the guidance of assembly instruction.

Security instructions

Before assembling check whether all parts listed in the parts list have been delivered. Do not start assembling if parts are missing or damaged.

A failure to assemble this product correctly could cause damage or result in serious injury! Before assembling make sure that you have enough space for the procedure. Assemble on a flat surface.

Keep the assembly instructions available at all times and follow each of the individual steps exactly.

During assembly, be careful with all the parts of the assembly (do not walk on them or distort them) and beware of shearing and trapping risks. Keep children and pets away while setting up the furniture.