




COSTWAY®

**Please give us a chance to make it right and do better !**

Contact our friendly customer service department for help first.  
Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana    UK office: Ipswich    AU office: Truganina



## Contact Us !

**Do NOT return this item.**

Contact our friendly customer service department for help first.



US: cs.us@costway.com  
UK: cs.uk@costway.com  
AU: cs.au@costway.com

## USER'S MANUAL





### 3 PCS RATTAN BAR SET HW68745

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.




## Before You Start


- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



(1 x Table)




(2 x Chair)




### Notice

1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. **Note:** If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.


## Part & Hardware List




Ax4  
Chair Leg Frame




Bx2  
Chair Seat Frame




Cx4  
Stretcher



Dx1  
Table Top Frame




Ex2  
Front Frame




Fx1  
Table Left Frame




Gx1  
Table Right Frame



Hx2  
Bottom Frame




Ix1  
Table Glass




Jx2  
Seat Cushion



① x16  
Bolt M6x15mm



② x24  
Bolt M6x40mm




③ x2  
Bolt M6x60mm



④ x2  
Nut M6



⑤ x44  
W6x1 Washers



⑥ x2  
Allen key M4




⑦ x1  
Spanner

## STEP 1


(2 x Chairs assembly)

Connect Chair leg frame (A), & Stretcher (C) with Bolt (1) & Washers (5)




## STEP 2

Connect Part from STEP 1 & Chair leg frame (A) with Bolt (1) & Washers (5)




## STEP 3

Connect Part from STEP 2  
& Chair seat frame (B) with  
Bolt (2) & Washers (5)



## STEP 4

Put on Seat Cushion (J) to  
complete Chair




Adjustable feet pads

## STEP 5


(1 x Table assembly)

Connect Front frame (E) & Front frame  
(E) with Bolt (3) & Washers (5) & Nut (4)




## STEP 6

Connect Part from STEP 5 & Table Right frame  
(G) with Bolt (2) & Washers (5)




## STEP 7

Connect Part from STEP 6 & Bottom frame (H) with Bolt (2) & Washers (5)




## STEP 8

Connect Part from STEP 7 & Table Left frame (F) with Bolt (2) & Washers (5)




## STEP 9

Connect Part from STEP 8 & Table top frame (D) with Bolt (2) & Washers (5)




## STEP 10

Put on Table glass (I) to complete the Table



## STEP 11



## Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

## Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since

Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.